




Danger of electrical shock, burns or death. Always remove all power sources before attempting any repair, service or diagnostic work. Power can be present from shore power, generator, inverter or battery. All power sources must be disabled and secured before performing any service.


## 

If you lack the skills, tools or equipment to perform diagnostic or repair work leave such work to an authorized Winnebago Industries dealer or other qualified shop.









	8	7	6	5	4		3	2		1
O6 F 33V              D0 NOT SCALE DRAWING              L1 FOR MORE INFORMATION SEE LOAD CENTER ASM.             NOTES:	D	TOR-WIRE, NM 02-000 -24B (8) 01-000 (2) 12B (2) PUR-2 40D THROW IN #3		BRACKET-MODULE MOUNT IS4367-01-CHT SCREW G39-10-12U (4)		NEG CABLE FRO WIRE ASM-INVE POS CABLE FRO WIRE ASM-INVE 2 REMOTE ON/O CONNECTION WI AC INPUT CORD AC OUTPUT HARD WIRE OPENING				
Image: Trice: WIRING INSTL-BODY, 110V   NOTES: PMET NO									06 F3	
VI FOR MORE INFORMATION SEE LOAD CENTER ASM.     NOTES:									TITLE:	
		LOAD CENTER ASM.							WIRING INSTL-	-BODY,110V
8 7 6 5 <b>1</b> 4 3 2 1 1/8/2005	8	7	6	5	<b>†</b> 4		3	2		