



If you lack the skills, tools or equipment to perform diagnostic or repair work leave such work to an authorized Winnebago Industries dealer or other qualified shop.

Danger of electrical shock, burns or death. Always remove all power sources before attempting any repair, service or diagnostic work. Power can be present from shore power, generator, inverter or battery. All power sources must be disabled and secured before performing any service.





Copyright © 2015 Winnebago Industries, Inc.





8	7	E






		78J	ELECTR	ICAL SYSTEM	1-50 AMP	
		265	CODES/S	TANDARDS-C	SA/CMVSS	
		1B1 CODES/STANDARDS USA			A	
		1B1	265	78J		
		FIRST USED	1	5 J38	Q	7
۱L	FOR ELECTRICAL	Γ		SCALE D	RAWING	
IS 0	X-X CALLOUTS SEE DWG NO. 121339-01-000	TITLE:	RING	INSTL-B	ODY,11	
		SHEET 4		PART NO 190)014	EV
	2			1	15-Jun-20	15


D


С

В



	2	1 No 190014	
			D
WIRI			
10 G FRO BRE	NPUT GA WIRE M MAIN AKER PANEL TAIL EB		С
itpu wii invi ker iil E	RE ERTER 1 PANEL		
N			←
2			B
		78J ELECTRICAL SYSTEM-50 AMP 265 CODES/STANDARDS-CSA/CMVSS 1B1 CODES/STANDARDS USA 1B1 265 78J FIRST USED 15 J38Q	14 *>
AL NS 10	X-X FOR ELECTRICAL CALLOUTS SEE DWG NO. 121339-01-000	DO NOT SCALE DRAWING TITLE: WIRING INSTL-BODY,110V SHEET 5 PART NO 190014	*1900
	2	1 15-Jun-2015	





8	7	6