



- ⑨ USE WIRE LU WITH REAR CAP ONLY.
- ⑧ USE WITH FIBERGLASS TRANSITION PANEL ONLY.
- ⑦ USE WITH MOTOR AID HEATER ONLY.
- ⑥ USED ONLY IF TRAY IS NOT CHASSIS SUPPLIED.
- ⑤ SEE DRAWING 92101 NOTE 6 FOR LOCATION OF WIRE ASM.
- 4. USE WIRE TIES 8343-01 AND WIRE CLAMPS 10497-01-000 APPROXIMATELY 600 MM ON CENTER UNLESS OTHERWISE SPECIFIED.
- 3. USE EXISTING HOLES IN WHEEL WELL FOR MOUNTING TRAY AND SUPPORT ASSEMBLY.
- 2. SECURE CONDUIT 41953-01-000 OVER ALL WIRE IN CONTACT WITH SHARP EDGES.
- 1. LEGEND: — — — FORD WIRING — — — WINNEBAGO WIRING - - - - CABLE.

'88 W/IF427RT	
OPTN CHRP P/E M/E CDR	UNDESIGNED TOLERANCES ARE: MATERIAL HOLE DIA (1) ± 0.15 ONE-PLATE (1) ± 0.1 HO-PLATE (1) ± 0.05 ANGLE THRU HOLES PROJECTION
PART NO DIA # SCALE: 1/10 ALL DIMENSIONS ARE IN MILLIMETERS	TITLE: WIRE INSTALLATION-CHASSIS SHEET 1 OF 1 REF: 88605