



- ⑦ USE WITH MOTOR AID HEATER ONLY.
- ⑥ USED ONLY IF TRAY IS NOT CHASSIS SUPPLIED.
- ⑤ SEE DRAWING 92101-01-000 NOTE 6 FOR LOCATION OF WIRE ASM.
- 4. USE WIRE TIES 8343-01 AND WIRE CLAMPS 10497-01-000 APPROXIMATELY 600 MM ON CENTER UNLESS OTHERWISE SPECIFIED.
- ③ USE EXISTING HOLES IN WHEEL WELL FOR MOUNTING TRAY AND SUPPORT ASSEMBLY.
- 2. SECURE CONDUIT 41953-01-000 OVER ALL WIRE IN CONTACT WITH SHARP EDGES.
- 1. LEGEND: --- FORD WIRING --- WINNEBAGO WIRING --- CABLE.

| | |
|-----------------------------------|-----------------------------|
| WINNEBAGO 90 W/IF327RB | |
| DATE | UNSPECIFIED TOLERANCES ARE: |
| CHKD | WELD DIM (R) .125 |
| FILE | ONE-PLATE (R, X) .1 |
| IN E | HO-PLATE (R, X) .003 |
| IN E | ANGLE .002 |
| CONTR | INDUS. WELD PROTECTION |
| LAUNCH | INDUS. WELD PROTECTION |
| TITLE: WIRE INSTL-CHASSIS | |
| DATE | SCALE: 0-1 |
| ALL DIMENSIONS ARE IN MILLIMETERS | SHEET 1 OF 1 |
| WINNEBAGO | 98710 |