


DVD HOME THEATER SYSTEM




The Blu Ray/DVD Home Theater System operates from 120-volt AC household current, so you must have either the shoreline connected, the generator running, or the inverter turned on (if equipped).

Set TV Video Input

- Power “ON” TV, HDMI Video Selection System, and Blu Ray DVD Player.
- Determine which TV you want to use (e.g. BEDROOM for bedroom TV) and select “Home Theater” from the HDMI Video Selection System (or the HDMI Video Selector Control or Secondary Source Selector).
- On the TV remote, press the **POWER** or **FUNCTION/TV SOURCE** button and select “HDMI 1”.



- Press the **FUNCTION** button on the Blu Ray DVD Player remote and select “BD/DVD” from the DVD player display screen.




- Scroll to the Video tab on the TV and select the movie that you want to watch.

The TV will display the satellite logo when the correct input is selected.

NOTE: Audio for the Home Theater System is installed around the lounge TV only.

Play Blu Ray/DVD Through Home Theater

- Insert Blu Ray DVD into player. The disk will begin to load automatically. TV screen will typically show “READING” or “LOADING”.
- The DVD may load directly to the main title/menu screen or it may begin to play previews. You may be able to skip previews if desired by pressing the Advance button until you see the main menu screen.
- When the main menu screen appears, use the **ENTER** or **PLAY** buttons on the remote




to select the desired entry and press the **ENTER** or **PLAY** buttons on the Blu Ray DVD Player remote (or “Play” button on DVD Player) to begin playing the feature.

- Volume is adjusted with the DVD remote or volume control on DVD Player.

TV Sound through Home Theater Speakers (Lounge TV Only)


When watching TV programs (broadcast, cable, or satellite), the TV normally plays sound through its own built-in stereo speakers. To connect TV sound output to home theater speakers for a richer sound quality, follow these steps:

- Turn the TV and Blu Ray/DVD Home Theater ON.
- Select the TV channel you wish to watch.
- Press the **FUNCTION** button on the Blu Ray DVD Player remote to set Home Theater to “Audio” mode. Select Sound Mode + or - from the DVD player remote to select listening mode.
- Turn TV and/or Home Theater volume up.




To Listen to FM Radio Through Home Theater

- Power “ON” TV, HDMI Video Selection System, and Blu Ray/DVD Home Theater.
- Determine which TV you want to view radio source from (e.g. EXTERIOR for Exterior Entertainment Center TV) and select “HOME THEATER” from the HDMI Video Selection System.
- On the TV remote, press the SOURCE or FUNCTION/TV SOURCE button and select “HDMI INPUT 1”.



- On the Blu Ray DVD Player remote, press the FUNCTION button and select “FM TUNER”.



Further Information

Refer to the manufacturer’s user guide provided in your InfoCase for complete operating instructions.

Audio-Video System Basic Operation Guide

JOURNEY Meridian

NOTE: See your InfoCase for specific operating guides for audio and video components.

