





DANGER

Danger of electrical shock, burns or death. Always remove all power sources before attempting any repair, service or diagnostic work. Power can be present from shore power, generator, inverter or battery. All power sources must be disabled and secured before performing any service.



CAUTION

If you lack the skills, tools or equipment to perform diagnostic or repair work leave such work to an authorized Winnebago Industries dealer or other qualified shop.



WINNEBAGO		98 F26WU
DRN	D. BILLY	DATE 1/27/97
CHK	J. WILLE	DATE 4/22/97
DR	B. WELLES	DATE 4/22/97
D/E	D. WITKAMP	DATE 4/22/97
COM	R. MUEHLER	DATE 4/22/97
DRN	TITLE: WIRING DIAGRAM-BODY 110V	
DRN	SCALE: NONE	SHEET 1 OF 1
ALL DIMENSIONS ARE IN MILLIMETERS		