




DANGER

Danger of electrical shock, burns or death. Always remove all power sources before attempting any repair, service or diagnostic work. Power can be present from shore power, generator, inverter or battery. All power sources must be disabled and secured before performing any service.



CAUTION

If you lack the skills, tools or equipment to perform diagnostic or repair work leave such work to an authorized Winnebago Industries dealer or other qualified shop.



- ④ TO THIS JUNCTION BOX WITH EXTERIOR ENTERTAINMENT CENTER.
- ③ GO DIRECTLY TO GALLEY CABT RECP WITH OUT EXTERIOR ENTERTAINMENT CENTER.
- ② WIRE ROUTED IN ROOF.
- ① GFI CIRCUIT BREAKER

(EUROPEAN 220 VOLT WIRING)
98 F25RC