




DANGER

Danger of electrical shock, burns or death. Always remove all power sources before attempting any repair, service or diagnostic work. Power can be present from shore power, generator, inverter or battery. All power sources must be disabled and secured before performing any service.



CAUTION

If you lack the skills, tools or equipment to perform diagnostic or repair work leave such work to an authorized Winnebago Industries dealer or other qualified shop.



- NOTES:
- ① SEE WIRING DIAGRAM INVERTOR, CHASSIS SHT 4, F-2 FOR ADDITIONAL INFORMATION.
 - ② CHASSIS SUPPLIED.
 - ③ SEE WIRING INSTL-CHASSIS FOR FUTURE INFORMATION.
 - ④ SEE MANUFACTURER'S DIAGRAM FOR ADDITIONAL INFORMATION.
 - ⑤ SEE SHT 2 FOR ADDITIONAL INFORMATION.

