




DANGER

Danger of electrical shock, burns or death. Always remove all power sources before attempting any repair, service or diagnostic work. Power can be present from shore power, generator, inverter or battery. All power sources must be disabled and secured before performing any service.



CAUTION

If you lack the skills, tools or equipment to perform diagnostic or repair work leave such work to an authorized Winnebago Industries dealer or other qualified shop.



- NOTES:
- CONNECT PURPLE-2 TO INVERTER WITH FEATURE (40B).
 - FOR USE WITH SHELLS ONLY.
 - SLIT AS NEEDED TO RUN WIRES.
 - WHERE WIRES PASS THROUGH HOLES IN STEEL AND ARE NOT OTHERWISE PROTECTED, USE GROMMET 92908-02-000.
 - REMOVE VINYL FROM CUTOUT AT INSTALLATION.
 - NOT USED WITH (20C) SOUND SYSTEM-DLX.

VIEW CF-CF (20C)

VIEW CG-CG (20C)

(X-X)
FOR
DETAIL
CALLOUTS
SEE DWG NO
130375-01-000

- (40F) INVERTER-DC/AC-130 WATT
- (25F) DIGITAL VIDEO DISC PLAYER
- (20C) SOUND SYS. DLX. W/O-SURROUND
- (40B) INVERTER-DC/AC. 300 WATT
- (72H) VCR
- (42R) TV-25" COLOR
- (35P) VIDEO SELECTION SYSTEM
- (20F) DELUXE SOUND SYSTEM-WITHOUT
- (193) TV ANTENNA

02 G SERIES
WIRING INSTL-TV/VCR_FRONT
DO NOT SCALE DIMENSIONS
SHEET 3 OF 10 I.F. No. 137576