




DANGER

Danger of electrical shock, burns or death. Always remove all power sources before attempting any repair, service or diagnostic work. Power can be present from shore power, generator, inverter or battery. All power sources must be disabled and secured before performing any service.



CAUTION

If you lack the skills, tools or equipment to perform diagnostic or repair work leave such work to an authorized Winnebago Industries dealer or other qualified shop.



2 CUT LABEL IN HALF AND USE PORTION THAT READS WATER PUMP.

1 ALL WIRES TO BE CLAMPED WITH CLAMP 10495-01-000
OR CLIP 80734-01-000 EVERY 700, USE SCREW G67-10-12B
UNLESS OTHERWISE SPECIFIED.

NOTES:

FOR ELECTRICAL
TORQUE
SPECIFICATIONS
SEE DWG NO.
128783-01-000


FOR ELECTRICAL
CALLOUTS
SEE DWG NO.
121339-01-000

265 CODES/STANDARDS-CSA/CMVSS

1B1 CODES/STANDARDS USA

1B1 265


		COPYRIGHT 2003 WINNEBAGO INDUSTRIES, INC.	
DFTR	ORIG. DATE		
CHKR	ALL DIMENSIONS ARE IN MILLIMETERS		
P.E.	FIRST USED		
M.E.	03 D30B		
DSNR			
UNSPECIFIED TOLERANCES ARE: WHOLE DIM (X) ± 1 ONE-PLACE (X.X) ± 1.5 TWO-PLACE (X.XX) ± 0.50 ANGLE ± 1°		MATERIAL:	
THIRD ANGLE PROJECTION			
DO NOT SCALE DRAWING			
TITLE: WIRING INSTL-BODY, 12V			
SHEET 1 OF 4		PART NO 141298	
REF: 138703 1 02/28/03			







DETAIL BA

SWITCH-ROCKER
135740-01-CHT (2)
SWITCH-BASE
135741-02-CHT
SWITCH-BEZEL
135742-15-CHT
SCREW
G11-08-08U (4)

LIGHT-READING
132427-01-CHT (2)
SCREW
G13-06-16U (6)



NOTES:



- 48Q SATELLITE DISH & ELEV.SENSOR
- 265 CODES/STANDARDS-CSA/CMVSS
- 1B1 CODES/STANDARDS USA

FIRST USED	03 D30B
TITLE	DO NOT SCALE DRAWING
WIRING INSTL - BODY, 12V	
SHEET 4	PART NO 141298

NOTES:

2 SENSOR SUPPLIED WITH SATELLITE ASSEMBLY

1 SEE DWG 76319-01-000 FOR INSTALLATION INSTRUCTIONS.