




DANGER


Danger of electrical shock, burns or death. Always remove all power sources before attempting any repair, service or diagnostic work. Power can be present from shore power, generator, inverter or battery. All power sources must be disabled and secured before performing any service.





CAUTION


If you lack the skills, tools or equipment to perform diagnostic or repair work leave such work to an authorized Winnebago Industries dealer or other qualified shop.




































WIRING DIAGRAM-OVHD
(WIRE ASM 133125)




WIRING DIAGRAM-COMPT, LAMPS
(WIRE ASM 138407-02)




WIRING DIAGRAM-BATH WALL
(WIRE ASM 131881-04)




WIRING DIAGRAM-GEN, ADAPTER, LP
(WIRE ASM 130332-01)



WIRING DIAGRAM-GEN, ADAPTER, DIESEL
(WIRE ASM 130332-02)





WIRING DIAGRAM-COMPT LAMPS
(WIRE ASM 138251)



WIRING DIAGRAM-COMPT LAMPS
(WIRE ASM 138219)

NOTES:



NOTE
NOTES:

FIRST USED		03 P39WD	
TITLE:		DO NOT SCALE DRAWING	
SHEET 7		PART NO 142838	
DATE		03/03/03	