







**DANGER**

**Danger of electrical shock, burns or death.** Always remove all power sources before attempting any repair, service or diagnostic work. Power can be present from shore power, generator, inverter or battery. All power sources must be disabled and secured before performing any service.





**CAUTION**


If you lack the skills, tools or equipment to perform diagnostic or repair work leave such work to an authorized Winnebago Industries dealer or other qualified shop.


WIRING DIAGRAM-CHASSIS  
(WIRE ASM 145455 REV F)


|                             |                                                                                       |
|-----------------------------|---------------------------------------------------------------------------------------|
| <b>WINNEBAGO®</b>           |                                                                                       |
| DFT#                        | ORIG. DATE                                                                            |
| CHK#                        | ALL DIMENSIONS ARE<br>IN MILLIMETERS                                                  |
| P.E.                        |                                                                                       |
| W.E.                        | FIRST USED                                                                            |
| DSNR                        | 04 P34H                                                                               |
| UNSPECIFIED TOLERANCES ARE: | MATERIAL:                                                                             |
| WHOLE DIM (X) :             |                                                                                       |
| ONE-PLACE (X,X) :           |                                                                                       |
| TWO-PLACE (X,XX) :          |                                                                                       |
| ANGLE :                     |                                                                                       |
| THIRD ANGLE<br>PROJECTION   |  |
| DO NOT SCALE DRAWING        |                                                                                       |
| TITLE:                      |                                                                                       |
| WIRING DIAGRAM-BODY, 12V    |                                                                                       |
| SHEET 1 OF 9                | PART NO 144816                                                                        |

































WIRING DIAGRAM-SIDEWALL  
(WIRE ASM 129128-02 REV-C)




WIRING DIAGRAM-EXTENSION, 2 PIN  
(WIRE ASM 133572-01-008 REV-E)




WIRING DIAGRAM-GEN ADAPTER,LP  
(WIRE ASM 130332-01 REV-C)



WIRING DIAGRAM-GEN ADAPTER,DIESEL  
(WIRE ASM 130332-02 REV-C)




WIRING DIAGRAM-ENTERTAINMENT CENTER  
(WIRE ASM 125853-04 REV-L)




WIRING DIAGRAM-OVHD  
(WIRE ASM 133231-03 REV-E)


SEE MANUFACTURER'S DIAGRAM FOR ADDITIONAL INFORMATION.



WIRING DIAGRAM-SIDEWALL  
(WIRE ASM 140487 REV-A)




WIRING DIAGRAM-SIDEWALL,RR  
(WIRE ASM 134061-03 REV-E)



WIRING DIAGRAM-SLIDEOUT,REAR  
(WIRE ASM 137456 REV-E)

|                      |   |                         |
|----------------------|---|-------------------------|
| FIRST USED           |   | 04 P34H                 |
| DO NOT SCALE DRAWING |   |                         |
| TITLE:               |   | WIRING DIAGRAM-BODY,12V |
| SHEET                | 6 | PART NO 144816          |




WIRING DIAGRAM-OVHD  
(WIRE ASM 145000 REV-A)




WIRING DIAGRAM-RESISTOR, FAN  
(WIRE ASM 140195 REV-A)


|                                 |   |         |        |
|---------------------------------|---|---------|--------|
| FIRST USED                      |   | 04 P34H |        |
| DO NOT SCALE DRAWING            |   |         |        |
| TITLE: WIRING DIAGRAM-BOCY, 12V |   |         |        |
| SHEET                           | 7 | PART NO | 144816 |



WIRING DIAGRAM-COMPT LAMPS  
(WIRE ASM 138219 REV-E)






WIRING DIAGRAM-COMPT LAMPS  
(WIRE ASM 140498 REV-B)



|            |                           |                |
|------------|---------------------------|----------------|
| FIRST USED | 04 P34H                   |                |
| TITLE      | DO NOT SCALE DRAWING      |                |
| TITLE      | WIRING DIAGRAM-BODY, 12 V |                |
| SHEET      | 8                         | PART NO 144816 |





|                                    |  |         |        |
|------------------------------------|--|---------|--------|
| FIRST USED                         |  | 04 P34H |        |
| DO NOT SCALE DRAWING               |  |         |        |
| TITLE:<br>WIRING DIAGRAM-BODY, 12V |  |         |        |
| SHEET X                            |  | PART NO | 144816 |