



Danger of electrical shock, burns or death. Always remove all power sources before attempting any repair, service or diagnostic work. Power can be present from shore power, generator, inverter or battery. All power sources must be disabled and secured before performing any service.

If you lack the skills, tools or equipment to perform diagnostic or repair work leave such work to an authorized Winnebago Industries dealer or other qualified shop.





		SHOWER CEILING JC JC JC PF PE	SWITCH-ROCKER 135740-01-CHT (2) SWITCH-BASE 135741-02-CHT SWITCH-BEZEL 135742-15-CHT SCREW GII-08-08U (4)	SL 1	IDEOUT ROOM	SWITCH ASM-K 138173-04-000	WIKEE O	0	SWITCH-HE/ 89308-05- 9LATE-SWI 9B351-01-(98351-01-(SCREW JA LABEL-SWI 9611-06-16, LABEL-SWI 134563-01	CHT TCH CHT	<u>76</u> D
		CEILING AISLE POR	CH SWITCH-ROCKER 135740-01-CHT (2) 135740-02-CHT SWITCH-BASE 135741-03-CHT	WARNING		C LABEL 116549-01-0	00	TURN OFF W	TANK HEATER hen Not In Use ators manual L CG (23T)		C
		O O O	SWITCH-ROCKER <u>IEZ</u> 135740-01-CHT SWITCH-BASE 135741-01-CHT SWITCH-BEZEL 135742-11-CHT SCREW G11-08-0BU (2)		ING HALL JE WX	WITCH-ROCKER 35740-01-CHT (2) WITCH-BASE 35741-02-CHT WITCH-BEZEL 35742-16-CHT CREW 11-08-08U (4)		ac xx			*
		ON AUX BATT OFF (FRONT SIDE)	WITCH-BATTERY,DISC 08357-06-000 CTUATOR-SWITCH 08356-11-CHT 98351-07-CHT 98351-07-CHT SCREW GII-06-10U (6)		NU SWITCH PH I3574 SWITCH 13574 SWITCH 13574 SWITCH SWITCH 13574 SWITCH	H-ROCKER -02-CHT H-BASE 1-01-CHT H-BEZEL 2-06-CHT B-08U (2)			O SWITCH-ROCKER 135740-01-CHT SWITCH-BASE 135741-01-CHT SWITCH-BEZEL 135742-01-CHT SCREW GII-08-08U (2) IL CJ		B
6	2	(BACK SIDE) DETAIL CC	6	5	•	4		FOR ELECTRICAL TORQUE SPECIFICATIONS SEE DWG NO. 128783-01-000	FOR ELECTRICAL CALLOUTS SEE DWG NO. 121339-01-000	(42J) TV-24" COLOR, STEREO W/REMOTE (42M) TV-19" COLOR W/STEREO (23T) HEATED HOLDING TANKS-PACKAGE (122) ENTRANCE STEP-ELEC. FIRST USED 05 331C/T D0 NOT SCALE DRAWING TITLE: WIRING INST-BODY, 12N SHEET 3 149376 15/6/2004	× A

Π

С

→

В

