

Danger of electrical shock, burns or death. Always remove all power sources before attempting any repair, service or diagnostic work. Power can be present from shore power, generator, inverter or battery. All power sources must be disabled and secured before performing any service.

If you lack the skills, tools or equipment to perform diagnostic or repair work leave such work to an authorized Winnebago Industries dealer or other qualified shop.

	8	7	6	5	4	3	2	1
								RELEASE A REVIDATE DWG 148638
⊂ C		UTE CABLE DOWN FT A-PILLAR		CABLE 2 1H4			74J SHROUD-CAMERA 37919-02-CHT 37919-03-CHT 37919-03-CHT 74J 9538-01-CHT 74J 9538-01-CHT 4 1 4 1 9 9 9 9 9 9 9 9 1 9 1 9	REV ZONE REVISION RECORD DATE OFTR-ORIG
В								74J REARVIEW MONITOR SYSTEM 15D GPS-NAVIGATION SYSTEM 1H4 REARVIEW MONITOR-WIRE PREP 1A5 REARVIEW MONITOR SYSTEM W/O
A	3 END STANDARD CABLE IN TH WITHOUT MONITOR. 1A5 2 RUN CABLE THRU LEFT HANE STANDARD ON ALL UNITS WI 1 PARTS SUPPLIED WITH CAME	1H4						COPYRIGHT 2004 WINNEBAGO INDUSTRIES, INC. OFTR OFT
L	NOTES: 8	7	6	5	↑ 4	3	2	SHEET 1 OF 2 PART NO 148638 REF: 145349-E 1 04/23/2004
	0	/		I J				1.2. V 1.3310 L 1 V4/23/2004

