



Danger of electrical shock, burns or death. Always remove all power sources before attempting any repair, service or diagnostic work. Power can be present from shore power, generator, inverter or battery. All power sources must be disabled and secured before performing any service.

## 

If you lack the skills, tools or equipment to perform diagnostic or repair work leave such work to an authorized Winnebago Industries dealer or other qualified shop.





8	7	6	5	↓	4	3	2		
								<sup>pwg</sup> 15760	D D D
с •	ET I I I I I I I I I I I I I I I I I I I	GND GND GND GND GND GND GND GND	B GRN (GROUND) AUDIO) TECTOR)		ROUTE THRU GROMME T 8386 - 0 I	E WIRES HOLE	B-DOOR ITCH/MAGNET- EP, ELECTRIC 6995-02-000 REW I-06-08B (4)		C B
A		6	5	•	4	FOR ELECTRICAL TOROUE SPECIFICATIONS SEE DWG NO. 128783-01-000	ELECTRICAL CALLOUTS SEE DWG NO. 121339-01-000	23T) HEATED HOLDING TANKS-PACKAGE 1E2) ENTRANCE STEP-ELECTRIC 1B1 265 FIRST USED 07 723D D0 NOT SCALE DRAWING TITLE: WIRING INSTL-BODY, 12V SHEET 3 PART NO 157603 REV 1 10/13/2006	A

8	7	6	5	4	3	2		1
	JA - JA - SWITC JA - JA - SWITC HR - JP SCREW G I I - CC SCREW G I L LABEL	2H-ROCKER 10-06-CHT H-BASE 11-01-CHT H-BEZEL 2-01-CHT 8-08U (2) -SWITCH 3-01-CHT	UNDERSTAND OPERATOR'S MANUAL BEF KEEP PEOPLE AND OBSTRUCTIONS CLE SLIDEOUT ROOM WHEN OPERATING TO INJURY AND/OR PROPERTY DAMAGE SLIDEOUT CONTROL SWITCH EXTEND EXTEND RETRACT	PLATE-SWITCH 144363-09-CHT SWITCH 108357-06-000 ACTUATOR 108356-02-CHT NUT D65-08-00B (2) LABEL 116220-01-000 DR,ER,DU		O STEP O F O N F E F R S DETAIL DG IE	G11-08-08U (2)	<u>№6157603</u> D
C →	CEILING JC PL JC CEILING JS74 SWITCI 13574 SWITCI 13574 SWITCI 13574 SWITCI 13574 SWITCI	H-ROCKER D-01-CHT H-BASE 1-01-CHT H-BEZEL 2-07-CHT	CEILING PE	SWITCH-ROCKER 135740-01-CHT SWITCH-BASE 135741-01-CHT SWITCH-BEZEL 135742-07-CHT SCREW GII-0B-0BU (2)			/ TCH-ROCKER 35740-01-CHT / TCH-BASE 15741-01-CHT / TCH-BEZEL 15742-01-CHT REW 1-08-08U (2)	C
В	DETAIL DC (FRONT SIDE)	LH 108356-11-CHT PLATE-SWITCH 98351-07-CHT SCREW G11-06-10U (2)	CE IL ING PORC	H SWITCH-ROCKER 135740-01-CHT (2) SWITCH-BASE 135741-02-CHT SWITCH-BEZEL 135742-19-CHT SCREW GII-08-08U (4)		SCREW	- ROCKER - 06 - CHT BASE - 01 - CHT - BEZEL - 35 - CHT - 08U (2) 23R DRAINAGE SYSTEM 53B WTR HTR-6GAL EL	
A 	7	6	5	4	FOR ELECTRICAL TORQUE SPECIFICATIONS SEE DWG NO. 128783-01-000	FOR ELECTRICAL CALLOUTS SEE DWG NO. 121339-01-000	IE2 ENTRANCE STEP-E   23T DRAINAGE SYSTEM   265 CODES/STANDARDS   IB1 CODES/STANDARDS   IB1 265   Ø7 72   D0 NOT   WIRING INSTL	A-HEATED S-CSA/CMVSS S-USA A 23D CDRAWING

