




**DANGER**

**Danger of electrical shock, burns or death.** Always remove all power sources before attempting any repair, service or diagnostic work. Power can be present from shore power, generator, inverter or battery. All power sources must be disabled and secured before performing any service.



**CAUTION**

If you lack the skills, tools or equipment to perform diagnostic or repair work leave such work to an authorized Winnebago Industries dealer or other qualified shop.



- NOTES:
- △6 SEE WIRING DIAGRAM-AUTO FOR ADDITIONAL INFORMATION.
  - △5 SEE MANUFACTURER'S DIAGRAM FOR ADDITIONAL INFORMATION.
  - △4 WIRE IN SIDEWALL.
  - △3 WIRE IN ROOF.
  - △2 LEAD SUPPLIED WITH CONVERTER.
  - △1 ALL OUTLETS DOWN STREAM AND INCLUDING THIS OUTLET ARE GROUND FAULT INTERRUPT PROTECTED.

- 1D5 ENTERTAINMENT CENTR/EXT W/CD
  - 53F WATER HEATER-ELEC. IGNITION
  - 53Z WTR HTR-6GAL/110/LP/MTR/AUTO
  - 265 CODES/STANDARDS-CSA/CMVSS
  - 12D ELECTRICAL SYSTEM 30 AMP
  - 1B1 CODES/STANDARDS USA
- 1B1 12D 265

**WINNEBAGO** COPYRIGHT 2006 WINNEBAGO INDUSTRIES, INC.

DFT	ORIG. DATE
CHKR	ALL DIMENSIONS ARE IN MILLIMETERS
P.E.	
M.E.	FIRST USED
DSNR	07 E30B

UNSPECIFIED TOLERANCES ARE: MATERIAL:

THIRD ANGLE PROJECTION

FOR ELECTRICAL TORQUE SPECIFICATIONS SEE DWG NO. 128783-01-000

(X-X) FOR ELECTRICAL CALLOUTS SEE DWG NO. 121339-01-000