




**DANGER**

**Danger of electrical shock, burns or death.** Always remove all power sources before attempting any repair, service or diagnostic work. Power can be present from shore power, generator, inverter or battery. All power sources must be disabled and secured before performing any service.



**CAUTION**

If you lack the skills, tools or equipment to perform diagnostic or repair work leave such work to an authorized Winnebago Industries dealer or other qualified shop.



- (40B) INVERTER DC/AC-300 WATT
- (645) RENTAL-CAMPING WORLD
- (1MB) CUSTOM FLOORPLAN - OFFICE
- (53B) WTR HTR-6GAL ELECTRIC/LP GAS
- (53F) WATER HEATER-ELEC. IGNITION
- (39A) EXT RECEPTACLE DPLX 120VAC
- (1L9) ENTERTAINMENT CENTER-CABOVER
- (61B) TV-26"AC, STEREO SYS, VDEO SEL
- (12D) ELECTRICAL SYSTEM 30 AMP
- (265) CODES/STANDARDS-CSA/CMVSS
- (1B1) CODES/STANDARDS-USA

- NOTES:
- 9 POWER CORD SUPPLIED WITH INVERTER.
  - 8 SEE WIRING DIAGRAM-BODY, 12V FOR ADDITIONAL INFORMATION.
  - 7 SEE MANUFACTURERS DIAGRAM.
  - 6 WIRE ROUTED BELOW FLOOR.
  - 5 ONLY WITH (1L9)
  - 4 WIRE ROUTED THRU ROOF.
  - 3 WIRE ROUTED THRU SIDEWALL.
  - 2 WIRE ROUTED THRU FLOOR.
  - 1 ALL OUTLETS DOWN STREAM AND INCLUDING THIS OUTLET ARE GROUND FAULT CIRCUIT INTERRUPT PROTECTED.

		COPYRIGHT 2011 WINNEBAGO INDUSTRIES, INC.
DFT-ORIG	ORIG. DATE	
CHKR	ALL DIMENSIONS ARE IN MILLIMETERS	
P.E.	FIRST USED	
M.E.	13 224V	
DSNR		
UNSPECIFIED TOLERANCES ARE:		MATERIAL:
WHOLE DIM (X)	:	-
ONE-PLACE (X.X)	:	-
TWO-PLACE (X.XX)	:	-
ANGLE	:	-
THIRD ANGLE PROJECTION	:	-
DO NOT SCALE DRAWING		REFER TO ES0018 FOR FASTENER TIGHTENING GUIDELINES
TITLE: WIRING DIAGRAM-BODY, 110V		
SHEET 1 OF 1	PART NO	182896
REF:	1	