


If you lack the skills, tools or equipment to perform diagnostic or repair work leave such work to an authorized Winnebago Industries dealer or other qualified shop.


Danger of electrical shock, burns or death. Always remove all power sources before attempting any repair, service or diagnostic work. Power can be present from shore power, generator, inverter or battery. All power sources must be disabled and secured before performing any service.




Copyright © 2014 Winnebago Industries, Inc.



	2	RELEASE REV DATE DWG 188930	
		REV ZONE REVISION RECORD DATE DFTR-ORIG	כ
			C
		•	_
	– ATS 3	12D ELECTRICAL SYSTEM 30 AMP 265 CODES/STANDARDS-CSA/CMVSS 1B1 CODES/STANDARDS USA 1B1 265 12D	3
AL IS O	K-x FOR FOR ELECTRICAL CALLOUTS SEE DWG NO. 21339-01-000 121339-01-000	Image: Strain of the strain	000000



	2	1 No 188930	
			D
(RCP-E (BLU) EXTERIOR		C
			3
AL NS 00	FOR X-X FOR ELECTRICAL CALLOUTS SEE DWG NO. 121339-01-000	1B1 265 12D FIRST USED 15 170A DO NOT SCALE DRAWING TITLE: WIRING INSTL-BODY, 110V	



8 7 6
