


If you lack the skills, tools or equipment to perform diagnostic or repair work leave such work to an authorized Winnebago Industries dealer or other qualified shop.


Danger of electrical shock, burns or death. Always remove all power sources before attempting any repair, service or diagnostic work. Power can be present from shore power, generator, inverter or battery. All power sources must be disabled and secured before performing any service.



Copyright © 2014 Winnebago Industries, Inc.



8 /



		D
RN)		С
RN)		←
		В
AL FOR	78J ELECTRICAL SYSTEM-50 AMP 265 CODES/STANDARDS-CSA/CMVSS 1B1 CODES/STANDARDS USA 1B1 265 78J FIRST USED 15 J35P	251 * ^{>}
US 0 ELECTRICAL CALLOUTS SEE DWG NO. 121339-01-000	DO NOT SCALE DRAWING TITLE: WIRING INSTL-BODY,110V	189
2	SHEET 2 PART NO 189251 REV 1 03-Nov-2014	*

NO 189251

