



DANGER

Danger of electrical shock, burns or death. Always remove all power sources before attempting any repair, service or diagnostic work. Power can be present from shore power, generator, inverter or battery. All power sources must be disabled and secured before performing any service.



CAUTION

If you lack the skills, tools or equipment to perform diagnostic or repair work leave such work to an authorized Winnebago Industries dealer or other qualified shop.

8	7	6	5	4	3	2	1
DWG NO	VENDOR P/N	SHEET	FIGURE	DWG NO	VENDOR P/N	SHEET	FIGURE
189715-01	90001	2	2	189715-36	90101	2	1
189715-02	90050	2	2	189715-37	90155	4	1
189715-03	90100	2	1	189715-38	90251	4	2
189715-04	90150	2	1	189715-39	90402	2	1
189715-05	90200	2	3	189715-40	90302	4	2
189715-06	90250	2	1	189715-41	90356	2	2
189715-07	90300	2	2	189715-42	90452	2	2
189715-08	90350	2	2	189715-43	90506	4	2
189715-09	90400	2	1	189715-44	90002	2	2
189715-10	90450	2	2	189715-45	90051	2	2
189715-11	90500	2	1	189715-46	90554	3	3

RELEASE	REV/DATE	DWG NO	189715
REV ZONE	REVISION RECORD	DATE	DFT-ORIG

189715-12	90550	2	3	
189715-13	90151	3	1	
189715-14	90201	3	3	
189715-15	90301	3	2	
189715-16	90351	3	2	
189715-17	90451	3	2	
189715-18	90501	3	1	
189715-19	90152	3	1	
189715-20	90352	3	2	
189715-21	90502	3	1	
189715-22	90552	3	3	
189715-23	90353	3	2	
189715-24	90503	3	1	
189715-25	90401	4	1	
189715-26	90050B	2	2	3
189715-27	90100B	2	1	3
189715-28	90153	2	1	3
189715-29	90300B	4	2	3
189715-30	90354	2	2	3
189715-31	90500B	2	1	3
189715-32	90301B	4	2	
189715-33	90154	3	1	3
189715-34	90355	3	2	3
189715-35	90505	3	1	3




FIGURE 1
(6 POSITION SWITCH PANEL)




FIGURE 2
(10 POSITION SWITCH PANEL)





FIGURE 3
(10 POSITION SWITCH/LCD PANEL)

3 USED WITH DUAL SHADE MODULE SYSTEM.
 2. ALL DIMENSIONS ARE FOR REFERENCE ONLY.
 1. SUGGESTED VENDOR: FIREFLY INTEGRATIONS; P/N: SEE TAB.


NOTES:

		COPYRIGHT 2014 WINNEBAGO INDUSTRIES, INC.
DFT-ORIG	ORIG. DATE	
CHKR	ALL DIMENSIONS ARE IN MILLIMETERS	
P.E.		
M.E.	FIRST USED	
DSNR	15 R-SER	
UNSPECIFIED TOLERANCES ARE:		MATERIAL:
WHOLE DIM (X)	: 3	
ONE-PLACE (X.X)	: 1.5	
TWO-PLACE (X.XX)	: 0.50	
ANGLE	: 1°	
THIRD ANGLE PROJECTION		
DO NOT SCALE DRAWING	REFER TO ES0018 FOR FASTENER TIGHTENING GUIDELINES	
TITLE: PANEL-SWITCH		
SHEET 1 OF 4	PART NO	189715
REF:	1	09-Oct-2015


*189715 *A




189715-01
189715-44




189715-02
189715-26
189715-45




189715-03
189715-27
189715-36




189715-04
189715-28




189715-05




189715-06
189715-48




189715-07




189715-08
189715-30
189715-41




189715-09
189715-39



189715-10
189715-42




189715-11
189715-31




189715-12
189715-54

FIRST USED	15 R-SER		
TITLE:	DO NOT SCALE DRAWING		
	PANEL-SWITCH		
SHEET 2	PART NO	189715	REV
			09-Oct-2015


189715




189715-13




189715-14




189715-15




189715-16




189715-17




189715-18




189715-19
189715-33




189715-20
189715-34
189715-51




189715-21
189715-35



189715-22
189715-46




189715-23




189715-24

FIRST USED		15 R-SER	
DO NOT SCALE DRAWING			
TITLE: PANEL-SWITCH			
SHEET 3	PART NO	189715	REV
		1	09-Oct-2015


189715




189715-25




189715-29
189715-40




189715-32




189715-37




189715-38




189715-43




189715-47




189715-49



189715-50



189715-52



189715-53

FIRST USED	15 R-SER		
TITLE:	DO NOT SCALE DRAWING		
	PANEL-SWITCH		
SHEET 4	PART NO	189715	REV
			1 09-Oct-2015

189715