



DANGER

Danger of electrical shock, burns or death. Always remove all power sources before attempting any repair, service or diagnostic work. Power can be present from shore power, generator, inverter or battery. All power sources must be disabled and secured before performing any service.






CAUTION

If you lack the skills, tools or equipment to perform diagnostic or repair work leave such work to an authorized Winnebago Industries dealer or other qualified shop.

DWG NO
132482-01 (WIN)
132482-02 (LTA)

RELEASE DATE 11-13-82
REVISION RECORD
DATE BY REV




- (9) SHELL MODELS.
 - (8) NOT USED WITH (21V).
 - (7) FOR WIRES THAT GO THRU FLOOR.
 - (6) GATHER PURPLE AND GREEN WIRES ON WIRE ASM-IP, MAIN AND CB ANTENNA CABLE AND WRAP WITH LABEL. SEE DETAIL MC.
 - (5) ROUTE WASHER BOTTLE, UNDER HOOD LAMP AND HEATER CONTROL WIRES THROUGH HOLE IN STEEL ABOVE AND RIGHT OF ENGINE. USE GROMMET 23942-01-000.
 - (4) USE TIE WIRE 93147-01-000 TO SECURE WIRE ASM-IP, MAIN.
 - (3) WIRE ASM MAY BE ROUTED ON EITHER SIDE OF HOLE PATTERN DISTANCE SHOWN, AT END POINT OF PATH, LEAVE 675±50 MM OF WIRE.
 - (2) SEE ANTENNA INSTL-CB FOR ADDITIONAL INFORMATION.
- NOTES:
1. FOR ADDITIONAL INFORMATION SEE WIRING INSTL-CHASSIS.


- (12L) DOOR-DRIVER
- (102) SLIDEOUT ROOM-REAR RIGHTHAND
- (09L) SLIDEOUT ROOM FRONT LEFT
- (64H) HYDRAULIC LEVELING JACKS
- (40J) CB RADIO PREP
- (36N) FANS-DEFROSTER-AUXILIARY
- (21V) SOUND SYSTEM-DELUXE
- (28X) MIRRORS-EXTERIOR W/DEFROST

DRAWN		DATE		UNDESIGNED TOLERANCES ARE:		MATERIAL	
CHP	DATE	ONE-PLACE (1:1)					
REV	DATE	TWO-PLACE (1:1)					
DATE	DATE	THREE-PLACE (1:1)					
DATE	DATE	FOUR-PLACE (1:1)					
DATE	DATE	FIVE-PLACE (1:1)					
DATE	DATE	SIX-PLACE (1:1)					
DATE	DATE	SEVEN-PLACE (1:1)					
DATE	DATE	EIGHT-PLACE (1:1)					
DATE	DATE	NINE-PLACE (1:1)					
DATE	DATE	TEN-PLACE (1:1)					
DATE	DATE	ELEVEN-PLACE (1:1)					
DATE	DATE	TWELVE-PLACE (1:1)					
DATE	DATE	THIRTEEN-PLACE (1:1)					
DATE	DATE	FOURTEEN-PLACE (1:1)					
DATE	DATE	FIFTEEN-PLACE (1:1)					
DATE	DATE	SIXTEEN-PLACE (1:1)					
DATE	DATE	SEVENTEEN-PLACE (1:1)					
DATE	DATE	EIGHTEEN-PLACE (1:1)					
DATE	DATE	NINETEEN-PLACE (1:1)					
DATE	DATE	TWENTY-PLACE (1:1)					
DATE	DATE	TWENTY-ONE-PLACE (1:1)					
DATE	DATE	TWENTY-TWO-PLACE (1:1)					
DATE	DATE	TWENTY-THREE-PLACE (1:1)					
DATE	DATE	TWENTY-FOUR-PLACE (1:1)					
DATE	DATE	TWENTY-FIVE-PLACE (1:1)					
DATE	DATE	TWENTY-SIX-PLACE (1:1)					
DATE	DATE	TWENTY-SEVEN-PLACE (1:1)					
DATE	DATE	TWENTY-EIGHT-PLACE (1:1)					
DATE	DATE	TWENTY-NINE-PLACE (1:1)					
DATE	DATE	THIRTY-PLACE (1:1)					

WIRING INSTL-FRONT END
SHEET 1 OF 17
REF: 129049-F 1



DETAIL BA




VIEW BB-BB

- NOTES:
- ② RUN ASSEMBLIES ALONG SIDEWALL THROUGH WIRE CLAMPS
 - ⚠ MOUNT LATCHES WITH TABS TOWARD CENTER OF DOOR.

FORD CHASSIS-20,500# GVWR

00 L-SERIES

TITLE: WIRING INSTL-FRONT END	
DATE: 11/14/82	REV: 1
SHEET: 2 OF 17	FIG NO: 132482






27E MODULE-DRL
 26S 134090-01-000
 SCREW
 G55-08-08U (2)

VIEW DA
 (CHASSIS WIRING SHOWN)

- 8 PUT ONE SEAL IN FRONT OF HOLE AT CAB PREP.
 - 7 4 RED WIRES (12V) TO OUTBOARD ISOLATED STUD.
 - 6 2 BLACK WIRES (GROUND) TO INBOARD ISOLATED STUD.
 - 5 FL IP WIRE ASM SHOULD BE TIED PRIOR TO INSTALLATION SEE DETAIL GA FOR TYING INSTRUCTIONS.
 - 4 ROUTE PARK BRAKE VALVE AND AIR LINES FOR DASH GAUGES THRU HERE. COVER WITH CONVOLUTE 41953 WHERE VISIBLE.
 - 3 DO NOT USE SEATBELT 2 PIN HOUSING.
2. BUNDLE AND SECURE ALL EXCESS WIRE.
1. ONLY FREIGHTLINER WIRING SHOWN FOR CLARITY. SEE OTHER VIEWS OF THIS DRAWING FOR OTHER WIRING IN THIS AREA.

27E CODES/STANDARDS-CMVSS
 26S CODES/STANDARDS-CSA/CMVSS
 1FB FREIGHTLINER CHASSIS-26,350#
 00 L-SERIES 1FB

TITLE		132482	
WIRING INSTL-FRONT END			
30 THE SCALE SHOWN	1:1	16 THE	132482
SHEET 3 OF 17			



NOTES:

(2) WITH SHELL.

(1) CHASSIS SUPPLIED.

(64D) SEATS-CAB-6-WAY PWR PEDESTAL

(28X) MIRRORS-EXTERIOR W/DEFROST


(16M) FORD CHASSIS-20.500# GVWR

(16M) 00 L-SERIES

TITLE: WIRING INSTL-FRONT END

30-38154-000-000 16M 132482

SHEET 4 OF 17 1.6



- Ⓟ REMOVE 10 AMP FUSE AND REPLACE WITH NOTED BREAKER.
- Ⓐ REMOVE LABEL FROM INSIDE OF PROVIDED PLASTIC COVER AND REAPPLY TO INSIDE OF DOOR ASM-ELECTRICAL BOX. THEN DISCARD SUPPLIED PLASTIC COVER.
- Ⓝ TRIM-VINYL 113452-01-000 ALL WIRE CONTACT SURFACES
- Ⓒ TRIM LABEL AS NECESSARY.
- Ⓛ MOUNT LATCHES WITH TABS TOWARD CENTER OF DOOR.

NOTES:


IFG FREIGHTLINER CHASSIS-26,350#

640 SEAT PED-6-WAY POWER DRIVER

00 L-SERIES IFG

TITLE: WIRING INSTL-FRONT END	FIG NO: 132482
NO. OF SHEETS: 5	SHEET NO: 5 OF 17

640 TO POWER DRIVER'S SEAT
WIRE ASM-POWER DRIVERS SEAT
108029-01-000




CONTROL PANEL WIRING


BRACKET-CIRCUIT BREAKER
115647-01-CHT
SCREW
G11-08-08U (4)
TRIM-VINYL
72368-02-000

LABEL-CIRCUIT
BREAKER, MAIN
93236-19-000


RELAY
63912-02-000 (4)
SCREW
G11-08-08B (4)



DETAIL FA



2 SEE SHT 1 FOR ROUTING INFORMATION.
1 SEE SHT 5 FOR ROUTING INFORMATION






DETAIL GA

1. USE WIRE TIES TO FORM FREIGHTLINER IP WIRE INTO THIS CONFIGURATION

NOTES:

00 L-SERIES

TITLE: WIRING INSTL-FRONT END	
NO. OF SHEETS: 17	SHEET NO. 7
FIG. NO. 132482	1 of 17




VIEW HD-HD (SWITCH ACTUATOR ORIENTATION)

VIEW HC-HC (SWITCH MOUNTING ORIENTATION)




VIEW HA-HA (ELECTRICAL INFORMATION)



DETAIL HB-HB

- 8 COVER CLEAR LEGEND ON BEZEL WITH FILM 77031-01-000 (W/BLANK) OR 77031-03-000 (W/OPTION)
- 7 SAME FOR ALL SWITCHES
- 6 SWITCH SHOWN WITHOUT HOUSING CONNECTED.
- 5 SAME FOR ALL DASH SWITCHES EXCEPT FOG LAMPS, AND GENERATOR SWITCH.
- 4 TIE TO WIRE ASM-IP, MAIN WITH WIRE TIE 93147-01-000
- 3 WITHOUT
- 2 WIRE TIE TO MAIN HARNESS WITH 8343-03-000.
- 1 CHASSIS SUPPLIED.

- 20F DELUXE SOUND SYSTEM-WITHOUT
- 16M FORD CHASSIS 20,500#/V10 ENG
- 36N FANS-DEFROSTER-AUXILIARY
- 28X MIRRORS-EXTERIOR W/DEFROST
- 21V SOUND SYSTEM-DELUXE
- 09L SLIDEOUT ROOM-FRONT LEFT




VIEW JA-JA (IFC)
(ELECTRICAL INFORMATION)

DETAIL JB-JB (IFC)

- NOTES:
- ⑥ COVER CLEAR LEGEND ON BEZEL WITH FILM 77031-01-000 (W/BLANK) OR 77031-03-000 (W/OPTION.)
 - ⑤ WITHOUT (36N)
 - 4. SEE DETAIL RA FOR INSTRUMENT CLUSTER ASSEMBLY INSTRUCTIONS
 - ③ WIRE TIE TO MAIN HARNESS WITH 8343-03-000.
 - ② MUST BE CALIBRATED FOR SPECIFIC CHASSIS. SEE CHART ON CLUSTER DRAWING.
 - ① CHASSIS SUPPLIED.

- ②0F DELUXE SOUND SYSTEM-WITHOUT
 - ①FC FREIGHTLINER CHASSIS-24, 850W
 - ③6N FANS-DEFROSTER-AUXILIARY
 - ②8X MIRRORS-EXTERIOR W/DEFROST
 - ②1V SOUND SYSTEM-DELUXE
- 00 L-SERIES

TITLE	WIRING INSTL-FRONT END
NO. OF SHEETS	16
SHEET NO.	9 OF 17
DATE	11/80
DRW. NO.	132482



- NOTES:
- ④ ALL GAUGES SUPPLIED WITH CHASSIS EXCEPT AS NOTED.
 - ③ EITHER MESSAGE CENTER PLUG WILL FIT EITHER SOCKET
 - ② ANY PLUG ON CLUSTER WIRE ASM WILL FIT ANY GAUGE
 - 1. ALL GAUGES, RETAINER CLIPS AND FASTENERS ARE CHASSIS SUPPLIED


99 1/2 L-SERIES ONLY

- ②7E CODES/STANDARDS-CMVSS
- ②65 CODES/STANDARDS-CSA/CMVSS


00 L-SERIES

DETAIL KA


TITLE: WIRING INSTL-FRONT END	
NO. OF SHEETS: 17	SHEET NO. 10 OF 17
DATE: 1/84	DESIGNER: J.E.H.
132482	




VIEW LC-LC (21V)





VIEW LC-LC (20F)




VIEW LD-LD



DETAIL LA



DETAIL LB




NOTES:



(36N) FANS-DEFROSTER-AUXILIARY

00 L-SERIES

TITLE: WIRING INSTL-FRONT END	
DO NOT SCALE DRAWING	FIG. NO. 1
SHEET 11 OF 17	132482



VIEW MA-MA (DELUXE SOUND INFORMATION) 21V







- NOTES:
- 4 PLUG FILTER INTO MONO TV INPUT AND RCA CABLE INTO FILTER.
 - 3 EDGE OF LABEL TO HANG JUST BELOW BOTTOM OF DASH.
 - 2 FOR ADDITIONAL INFORMATION SEE WIRING INSTL-BODY.
 - 1 ROUTE WITH WIRE ASM-IP, MAIN.

40U CB RADIO PREP

21V SOUND SYSTEM-DELUXE


OO L-SERIES

TITLE: WIRING INSTL-FRONT END	
30 THE SCALE SHOWN	FIG. NO.
SHEET 12 OF 17	132482



- 3 ROUTE THROUGH CLAMPS WITH WIRE ASM-IP, MAIN IN THIS AREA
- 2 COVER CLEAR LEGEND ON BEZEL WITH FILM 77031-01-000 (BLANK) OR 77031-03-000 (W/FEATURE)
- 1 FOR ADDITIONAL INFORMATION SEE WIRING INSTL-BODY

- 1FG FREIGHTLINER CHASSIS-26,350#
- 64H HYDRAULIC LEVELING JACKS
- 28X MIRRORS-EXTERIOR W/DEFROST
- 1B2 SLIDEOUT ROOM-REAR LEFTHAND
- 16M FORD CHASSIS-20,500# GVWR



① WIRE ASM-WIPER/WASHER
111096-03-000

LAMP
98024-01-CHT
SCREW
G39-08-10B
CONNECTOR
86028-01-000(2)

FROM WIRE ASM-
IP, MAIN

2 PIN HOUSING TO
WASHER BOTTLE PUMP

(2) FEMALE TERMINALS
TO EVAP. A/C PRESSURE SWITCH

FEMALE TERMINAL TO
EVAPORATOR THERMOSTAT

① WIRE ASM-HEADLAMP
126816-04-000

LAMP SOCKET
TO RIGHT SIDE MARKER LAMP
IN HEADLIGHT HOUSING
BULB 12V NO. 194
36196-01-000

(3) FEMALE TERMINALS
TO SIDE MARKER/
TURN SIGNAL LAMP
(SEE DETAIL PA)

(2) MALE TERMINALS
TO FOG LAMP

PARKLAMP ASM-SIDEMARKER, AMBER
126201-01-000 (RH)
126201-02-000 (LH)
SOCKET LAMP
112709-04-000(2)
BULB
112708-02-000(2)
NUT
MDD1K-05-000(2)
ANGLE-PARKLAMP
127836-0-CHT
BOLT
C26-04-188(2)
NUT
D39-04-008(2)

5 PIN HOUSING
TO WIPER MOTOR

TO CHASSIS WIRING

FORD HOUSING
TO BULK HEAD CONNECTOR

2 PIN HOUSING
TO WIRE ASM-CHASSIS

LAMP SOCKET
TO LEFT SIDE MARKER LAMP
IN HEADLIGHT HOUSING
BULB 12V NO. 194
36196-01-000

(3) FEMALE TERMINALS
TO SIDE MARKER/
TURN SIGNAL LAMP
(SEE DETAIL PA)

LAMP HOUSING
TO LEFT HEADLAMP

(2) MALE TERMINALS
TO FOG LAMP

TO HORN


(1) RING TERMINAL
TO GROUND BOLT

HORN
(CHASSIS SUPPLIED) ② ③

MK, MU
TO UNDER HOOD LAMP

FRAME ASM-HEADLAMP
126490-01-CHT (RH)
126490-01-CHT (LH)
BOLT
C26-05-20B (8)
NUT
D39-05-00B (8)

HEADLAMP-ASM
126200-01-000 (RH)
126200-02-000 (LH)
CLIP
124163-01-000(6)



DETAIL PA ⑤

⑤ CONNECT WIRES FROM WIRE ASM-HEADLAMP AS SHOWN TO PARK/TURN SOCKET. FILL WITH HOT MELT GLUE ONLY.

4. GATHER ALL EXCESS WIRE AFTER MAKING ALL CONNECTIONS AND BUNDLE AND SECURE WITH TIE-WIRE 8343-01-000 OR 93147-01-000.

③ MOUNT ON GROUND BOLT.


② CLEAN PAINT OFF METAL (BOLT) BEFORE CONNECTING GROUND TO INSURE CONTACT.

① SECURE WIRE ASM APPROX. EVERY 450 TO BATTERY CABLES AND BRACKETS. USE TIE-WIRE 8343-01-000 OR 93147-01-000 AS APPROPRIATE.

NOTES:

⑤M LAMPS-FOG
①GM FORD CHASSIS-20,500# GVWR
WINNEBAGO
00 L-SERIES ONLY

TITLE: WIRING INSTL-FRONT END
SHEET 14 OF 17



- (3) SECURE FOG LAMP IN FOG LAMP SUPPORT AND CENTER IN OPENING IN LOWER GRILLE.
- (3) LUBRICATE GROMMET FOR EASE OF INSTALLATION
- 4. GATHER ALL EXCESS WIRE AFTER MAKING ALL CONNECTIONS AND BUNDLE AND SECURE WITH TIE-WIRE 8343-01-000 OR 93147-01-000.
- (3) MOUNT ON GROUND BOLT.
- (2) CLEAN PAINT OFF METAL (BOLT) BEFORE CONNECTING GROUND TO INSURE CONTACT.
- (1) SECURE WIRE ASM APPROX. EVERY 450 TO BATTERY CABLES AND BRACKETS. USE TIE-WIRE 8343-01-000 OR 93147-01-000 AS APPROPRIATE.

NOTES:


(57M) LAMPS-FOG
 (16M) FORD CHASSIS 20.500#/V10 ENG

ITASCA
 00 L-SERIES

TITLE: WIRING INSTL-FRONT END	
DO NOT SCALE DIMENSIONS	FIG. NO.
SHEET 15 OF 17	16
132482	


FL CHASSIS WIRE ASM

WIRE ASM-HEADLAMP, FL, LEFT




DETAIL RA (3)

WIRE ASM-HEADLAMP, FL, LEFT



DETAIL RB (3)



LAMP
98024-01-CHT
SCREW
G39-08-108
CONNECTOR
58028-01-000(2)

WIRE ASM-IP, MAIN
FROM INTERIOR

(3) FEMALE TERMINALS
TO EVAP, A/C PRESSURE SWITCH

2 PIN HOUSING
TO WASHER BOTTLE PUMP

5 PIN HOUSING
TO FL CHASSIS WIRE ASM

3 PIN HOUSING
TO WIRE ASM-IP, MAIN

WIRE ASM-HEADLAMP, FL, RIGHT
132321-02-000

LAMP SOCKET
TO RIGHT SIDE MARKER LAMP
IN HEADLIGHT HOUSING
BULB 12V NO. 194
36196-01-000

(3) FEMALE TERMINALS
TO SIDE MARKER/
TURN SIGNAL LAMP
(SEE DETAIL PA)

(2) MALE TERMINALS
TO FOG LAMP

2 PIN HOUSING
TO WASHER BOTTLE

LAMP HOUSING
TO RIGHT HEADLAMP

PLATE-W/HOLE
119383-05-CHT(2)

PARKLAMP ASM-SIDEMARKER, AMBER
126201-01-000 (RH)
126201-02-000 (LH)
SOCKET-LAMP
112709-04-000(2)
BULB
112708-02-000(2)
NUT
MD01K-06-000(2)
ANGLE-PARKLAMP
127836-01-CHT
BOLT
C26-D4-188(2)
NUT
D39-04-008(2)

FRAME ASM-HEADLAMP
126490-01-CHT (RH)
126490-01-CHT (LH)
BOLT
C26-05-20B (8)
NUT
D39-05-00B (8)

HEADLAMP-ASM
126200-01-000 (RH)
126200-02-000 (LH)
CLIP
124163-01-000(6)

HORN
(CHASSIS SUPPLIED)

(2) MALE TERMINALS
TO FOG LAMP

PUMP-VACUUM
114802-01-000
SCREW
G11-08-12B (3)

WIRE ASM-HEADLAMP, FL, LEFT
132321-01-000

LAMP HOUSING
TO LEFT HEADLAMP

(3) FEMALE TERMINALS
TO SIDE MARKER/
TURN SIGNAL LAMP
(SEE VIEW TB-TB)

LAMP SOCKET
TO LEFT SIDE MARKER LAMP
IN HEADLIGHT HOUSING
BULB 12V NO. 194
36196-01-000

3 PIN HOUSING
TO WIRE ASM-IP, MAIN

(2) FEMALE TERMINALS
TO VACUUM PUMP

5 PIN HOUSING
TO WIPER MOTOR


WIRE ASM-IP, MAIN
FROM INTERIOR

- (2) ROUTE WIPER MOTOR AND VACUUM PUMP WIRES THRU HOLE IN STEEL ABOVE AND LEFT OF ENGINE. USE GROMET 88756-01.
- (1) MOUNT ON GROUND BOLT.

(IFC) FREIGHTLINER CHASSIS-24, 850W

WINNEBAGO
OO L-SERIES

TITLE		DRAWING NO.	
WIRING INSTL-FRONT END		132482	
OF SHEET	SHEET NO.	OF DRAWING	DWG NO.
16	17	16	17



WIRE ASM-IP, MAIN FROM INTERIOR

LAMP 98024-01-CHT SCREW C39-08-10B CONNECTOR 58028-01-000(2)

(3) FEMALE TERMINALS TO EVAP. A/C PRESSURE SWITCH

2 PIN HOUSING TO WASHER BOTTLE PUMP

TO RIGHT SIDE MARKER LAMP

3 PIN HOUSING TO WIRE ASM-IP, MAIN

WIRE ASM-HEADLAMP, FL. RIGHT 132322-02-000

LAMP HOUSING TO RIGHT HEAD LAMP

LAMP HOUSING TO RIGHT TURN SIGNAL LAMP

(2) MALE TERMINALS TO FOG LAMP

2 PIN HOUSING TO WASHER BOTTLE

5 PIN HOUSING TO FL CHASSIS WIRE ASM

WIRE ASM-IP, MAIN FROM INTERIOR

5 PIN HOUSING TO WIPER MOTOR (2)

TO LEFT SIDE MARKER LAMP

(2) FEMALE TERMINALS TO VACUUM PUMP

3 PIN HOUSING TO WIRE ASM-IP, MAIN

PUMP-VACUUM 114802-01-000 SCREW G11-08-12B (3)

LAMP HOUSING TO LEFT HEAD LAMP

WIRE ASM-HEADLAMP, FL. LEFT 132322-01-000

LAMP HOUSING TO LEFT TURN SIGNAL LAMP

TO HORN (SEE DETAIL RB)

HORN (CHASSIS SUPPLIED) (3)

(2) MALE TERMINALS TO FOG LAMP

FRAME ASM-HEADLAMP 125704-01-CHT (RH) 125704-02-CHT (LH)

PLATE ASM-STUD 106730-14-000(4) NUT D39-04-08B(8)

SCREW G42-04-12B (8)

HEADLAMP ASM 126199-01-000 (RH) 126199-02-000 (LH) BULB 118054-01-000 (2)

SUPPORT ASM-FOG LAMP 129268-01-000 (RH) 129268-02-000 (LH) SCREW G39-08-12U (8)

LAMP ASM-FOG 117827-01-000 (2) BULB (SUPPLIED W/LAMP) RIVET H16-06-04R (6)

GROMMET-MOUNTING, LIGHT 4" RD 126198-02-000 (2)

LAMP ASM-PARK/TURN, AMBER 126198-01-000 (2)

- ④ LUBRICATE GROMMET FOR EASE OF INSTALLATION
- ③ MOUNT ON GROUND BOLT.
- ② ROUTE WIPER MOTOR AND VACUUM PUMP WIRES THRU HOLE IN STEEL ABOVE AND LEFT OF ENGINE. USE GROMMET 88756-01-000.
- ① SECURE FOG LAMP IN FOG LAMP SUPPORT AND CENTER IN OPENING IN LOWER GRILLE.

ITD FREIGHTLINER CHASSIS-24.850#

ITASCA 00 L-SERIES

TITLE: WIRING INSTL-FRONT END	
TO THE SCALE SHOWN	FIG. NO.
SHEET 17 OF 17	132482