



DANGER

Danger of electrical shock, burns or death. Always remove all power sources before attempting any repair, service or diagnostic work. Power can be present from shore power, generator, inverter or battery. All power sources must be disabled and secured before performing any service.




CAUTION


If you lack the skills, tools or equipment to perform diagnostic or repair work leave such work to an authorized Winnebago Industries dealer or other qualified shop.

CONNECTS TO
 ELECTRIC
 STEP WIRING
 (BELOW STEP)

ELECTRIC STEP
 SWITCH
 (IN END OF
 GALLEY CABT)



LG
 LH
 LJ
 WH
 KA
 DK
 LM
 LL
 MP
 ES
 JT
 DJ
 DL
 LN
 LP
 DM
 ER
 HS



CONNECT TO
 WIRE ASM-COACH
 (SHT 2, H-14)
 (LOCATED BELOW
 REFRIGERATOR)

CONNECTS TO
 WIRE ASM-
 ELECTRICAL BOX
 (SHT 1, H-2)
 (INSIDE ELECTRICAL
 BOX ABOVE)



FEED THRU STUD
 (THRU CAB BULKHEAD
 PANEL ON DRIVER'S SIDE)


CONNECTS TO
 WIRE ASM-CHASSIS
 (SHT 1, C-5)
 (INSIDE COMPT
 AHEAD OF STEP)




CONNECTS TO
 WIRE ASM-CHASSIS
 (SHT 1, E-15)
 (LOCATED INSIDE
 ELECTRICAL BOX
 ABOVE STEP)



CONNECTS TO
 WIRE ASM-CHASSIS
 (SHT 1, F-16)
 (INSIDE ELECTRICAL
 BOX ABOVE)



12 VOLT
 CIRCUIT BREAKERS
 (INSIDE ELECTRICAL
 BOX ABOVE STEP)



(ON CHASSIS RAIL
 BY BATTERY COMPT)

WIRING DIAGRAM-ELECTRICAL BOX
 (WIRE ASM 124125-02)

ISOLATED STUD
 (NEAR CONVERTER)

TO UPPER BUS BAR

WIRING DIAGRAM-CHASSIS
 (WIRE ASM 135039-01)


DPTD		DATE	PROPOSED TOLERANCES ARE:	MATERIAL:
OWP	DATE	DATE	ANGLE FOR 141	+
P.E	DATE	DATE	ONE-PLACE 14.141	+
D.W	DATE	DATE	TWO-PLACE 14.141	+
OWP	DATE	DATE	THIRD PLACE	+
OWP	DATE	DATE	FOURTH PLACE	+
OWP	DATE	DATE	FIFTH PLACE	+
OWP	DATE	DATE	SIXTH PLACE	+
OWP	DATE	DATE	SEVENTH PLACE	+
OWP	DATE	DATE	EIGHTH PLACE	+
OWP	DATE	DATE	NINTH PLACE	+
OWP	DATE	DATE	TENTH PLACE	+
OWP	DATE	DATE	ELEVENTH PLACE	+
OWP	DATE	DATE	TWELFTH PLACE	+
OWP	DATE	DATE	THIRTEENTH PLACE	+
OWP	DATE	DATE	FOURTEENTH PLACE	+
OWP	DATE	DATE	FIFTEENTH PLACE	+
OWP	DATE	DATE	SIXTEENTH PLACE	+
OWP	DATE	DATE	SEVENTEENTH PLACE	+
OWP	DATE	DATE	EIGHTEENTH PLACE	+
OWP	DATE	DATE	NINETEENTH PLACE	+
OWP	DATE	DATE	TWENTIETH PLACE	+
OWP	DATE	DATE	ALL DIMENSIONS ARE IN MILLIMETERS	

WINNEBAGO 01 G37G

WIRING DIAGRAM-BODY.12V

SHEET 1 OF 6

135040



CONNECTS TO WIRE ASM-COACH (SHT 2, A-16) (LOCATED IN BASE OF REFRIG CABT)

CONNECTS TO ④ GENERATOR WIRING (IN GENERATOR COMPT)

CONNECTS TO WIRE ASM-IP MAIN (THRU CAB FLOOR ON LEFT SIDE)

CONNECTS TO WIRE ASM-ELECTRICAL BOX (SHT 1, F-3) (INSIDE ELECTRICAL BOX ABOVE)

CONNECTS TO WIRE ASM-ELECTRICAL BOX (SHT 1, G-3) (LOCATED INSIDE ELECTRICAL BOX ABOVE STEP)

④ CONNECTS TO AUTO HEATER


CONNECTS TO WIRE ASM-RIGHT (SHT 4, F-1) (LOCATED BELOW REFRIGERATOR)

- ④ SEE MANUFACTURER'S DIAGRAM FOR ADDITIONAL INFORMATION.
- ③ SEE WIRING DIAGRAM-AUTO LAMPS FOR ADDITIONAL INFORMATION.
- ② SEE SHT 4 FOR ADDITIONAL INFORMATION
- ① SEE WIRING DIAGRAM-AUTO FOR ADDITIONAL INFORMATION.


















NOTES:

GROUND
(ON FRAME RAIL BEHIND ENTRANCE STEP)


LP TANK



GROUND



CONNECTS TO WIRE ASM-RIGHT (SHT 4, A-5) (LOCATED ABOVE MICROWAVE)



NOTES: SEE MANUFACTURER'S DIAGRAM FOR ADDITIONAL INFORMATION.

CONNECTS TO WIRE ASM-COACH (SHT 2, A-6) (LOCATED IN SHOWER CABT ABOVE MONITOR PANEL)

CONNECTS TO WIRE ASM-TOILET WALL (SHT 5, E-1) (LOCATED IN FRONT TOILET WALL)

WIRING DIAGRAM ROOF (WIRE ASM 135042)

01 G37G

TITLE: WIRING DIAGRAM BODY 12V	
NO. OF SHEETS: 6	SHEET NO. 3 OF 6
DATE: 1.6	135040

CONNECTS TO WIRE ASM-COACH (SHT 2, A-10) (LOCATED BELOW REFRIGERATOR)

GROUND


ISOLATED STUD

ELECTRIC STEP KILL SWITCH


CONNECTS TO LOAD SHEDDER CONTROL BOARD



MARKER LAMP



CONNECTS TO WIRE ASM-COACH (SHT 2, A-7) (LOCATED BELOW REFRIGERATOR)



PORCH STEP LAMP SWITCH



CEILING LAMP SWITCH



COMPARTMENT LAMP




STEP LAMP













CONNECTS TO WIRE ASM-SIDEWALL (SHT 5, A-8) (LOCATED IN BASE OF REFRIGERATOR CABT)



REFRIGERATOR



CONNECTS TO WIRE ASM-ROOF (SHT 3, H-5) (LOCATED ABOVE MICROWAVE)



12V BREAKER PANEL (LOCATED IN GALLEY CABT)

WIRING DIAGRAM RIGHT (WIRE ASM 135973)

01 G37G

TITLE: WIRING DIAGRAM BODY_12V SHEET 4 OF 6

NOTES: SEE MANUFACTURER'S DIAGRAM FOR ADDITIONAL INFORMATION.

