



DANGER





Danger of electrical shock, burns or death. Always remove all power sources before attempting any repair, service or diagnostic work. Power can be present from shore power, generator, inverter or battery. All power sources must be disabled and secured before performing any service.



CAUTION

If you lack the skills, tools or equipment to perform diagnostic or repair work leave such work to an authorized Winnebago Industries dealer or other qualified shop.


CONNECTS TO WIRE ASM-ELECTRICAL BOX (SHT 1, C-4) (LOCATED IN STEP BOX)




- FM 14 WHT
- PA 14 WHT
- PM 14 WHT
- MP 16 WHT
- MS 16 WHT
- EED 12 WHT
- WE 14 WHT
- JN 14 WHT

WIRING DIAGRAM-CHASSIS (WIRE ASM 141253-01-000 REV.J)


COMPARTMENT LAMPS




CONNECTS TO WIRE ASM-ELECTRICAL BOX (SHT 1, D-2) (LOCATED IN STEP BOX)




CONNECTS TO WIRE ASM-ELECTRICAL BOX (SHT 1, D-2) (LOCATED IN STEP BOX)




CONNECTS TO WIRE ASM-SIDEWALL (SHT 5, D-3) (LOCATED BEHIND COUCH)




CONNECTS TO WIRE ASM-CHASSIS (SHT 1, A-5/B-5) (LOCATED IN STEP BOX)





CONNECTS TO WIRE ASM-CHASSIS (SHT 1, B-16) (LOCATED IN STEP BOX)




CONNECTS TO WIRE ASM-CHASSIS (SHT 1, D-7) (LOCATED IN STEP BOX)




ISOLATED STUD (LOCATED INSIDE BATTERY COMPARTMENT)



NEGATIVE BAR



12 VOLT BREAKERS (LOCATED IN STEP BOX)




GENERATOR

WIRING DIAGRAM-ELECTRICAL BOX (WIRE ASM 124125-02-000 REV.G)


WINNEBAGO		COPYRIGHT 2002 WINNEBAGO INDUSTRIES, INC.	
OFTR	ORIG. DATE	ALL DIMENSIONS ARE IN MILLIMETERS	
CHR		03 G33V	
P.E.		UNSPECIFIED TOLERANCES ARE:	
M.E.	FIRST USED	WHOLE DIM (XX)	:
DSNR		ONE-PLACE (X.X)	:
		TWO-PLACE (X.XX)	:
		ANGLE	:
		THIRD ANGLE PROJECTION	:
DO NOT SCALE DRAWING			
TITLE: WIRING DIAGRAM-BODY, 12V			
SHEET 1 of 6		PART NO 141037	

5 CONNECTS TO WIRE ASM-IP MAIN (LOCATED IN DRIVERS SIDE FLOOR PANEL)




- A1-WP 10 YEL
- A2-KS 14 YEL
- A3-
- B1-DJ 16 YEL
- B2-DK 16 WHT
- B3-DL 16 YEL
- B4-DM 16 WHT
- C1-KE 14 YEL
- C2-
- D1-LL 16 WHT
- D2-LM 16 WHT
- D3-LN 16 WHT
- D4-LP 16 YEL
- E1-MM 14 YEL
- E2-BBN 16 YEL
- F1-BBM 16 YEL
- F2-CCZ 16 YEL
- G1-DDA 16 YEL
- G2-CCY 16 YEL
- G3-LR 14 YEL
- G4-NA 14 YEL
- H1-KU 14 YEL
- H2-NH 14 YEL
- J1-AAT 16 YEL
- J2-AAU 16 WHT
- J3-AAW 16 YEL
- J4-AAX 16 WHT
- K1-
- K2-
- K3-

CONNECTS TO GENERATOR 4



- A-LN 16 WHT
- B-LM 16 WHT
- C-LL 16 WHT
- D-
- E-
- F-LP 16 YEL
- G-
- H-


CONNECTS TO WIRE ASM-COACH (SHT 2, D-18) (LOCATED BELOW GALLEY CABINETS)




- 1-LH 16 YEL
- 2-LJ 16 YEL
- 3-LL 16 WHT
- 4-LM 16 WHT
- 5-LN 16 WHT
- 6-LP 16 YEL
- 7-MM 14 YEL
- 8-NM 14 YEL
- 9-NW 14 YEL
- 10-WH 14 YEL
- 11-AAT 16 YEL
- 12-AAU 16 WHT

- 1-BBM 16 YEL
- 2-BBN 16 YEL
- 3-DDA 16 YEL
- 4-CCY 16 YEL
- 5-CCZ 16 YEL
- 6-DJ 16 YEL
- 7-DK 16 WHT
- 8-DL 16 YEL
- 9-DM 16 WHT
- 10-ER 14 YEL
- 11-ES 14 YEL
- 12-HS 16 YEL
- 13-JG 14 YEL
- 14-JT 16 YEL
- 15-LG 16 YEL

CONNECTS TO WIRE ASM-COACH (SHT 2, A-13) (LOCATED BELOW GALLEY CABINETS)




CONNECTS TO WIRE ASM-ELECTRICAL BOX (SHT 1, D-4) (LOCATED IN STEP BOX)



- 1-WP 10 YEL
- 2-

- 1-AAW 16 YEL
- 2-AAW 16 WHT
- 3-EEC 12 YEL
- 4-FFD 14 YEL

CONNECTS TO WIRE ASM-COACH (SHT 2, A-9) (LOCATED BELOW GALLEY CABINETS)




- 5 SEE WIRING DIAGRAM-AUTO FOR ADDITIONAL INFORMATION.
 - 4 SEE MANUFACTURER'S DIAGRAM FOR ADDITIONAL INFORMATION.
 - 3 GROUNDS ARE SHOWN AS A SINGLE LINE FOR EASE IN TRACING. EACH GROUND CIRCUIT IS SEPERATE IN THE HARNESS.
 - 2 NOT A SPLICE POINT. INDICATES ENTRY INTO WIRING HARNESS.
1. SPLICES ARE THEORETICAL AND MAY DIFFER IN THE HARNESS.

NOTES:

- 1-EEC 12 YEL
- 2-EED 12 WHT

CONNECTS TO WIRE ASM-SOFA (SHT 6, B-6) (LOCATED BEHIND COUCH)




- A-NA 14 YEL
- B-NH 14 YEL

CONNECTS TO WIRE ASM-HEADLAMP 5



CONNECTS TO REAR AUTO HEATER 4


- 1-PA 14 WHT
- 2-KS 14 YEL
- 3-
- 4-KU 14 YEL



- JT 16 YEL
- MP 16 WHT



- MP 18 WHT
- KD 18 WHT




- A-KA 12 YEL
- B-WH 14 YEL
- C-KD 18 WHT
- D-ES 14 YEL

ELECTRIC STEP 4





CONNECTS TO RED AND GRN TELEPHONE WIRES (LOCATED BELOW GALLEY) (SHT 2, D-23)



- 1-NM 14 YEL
- 2-PM 14 WHT
- 3-RED 18 WHT
- 4-GRN 18 WHT

NO CONNECTION (NOT USED ON THIS UNIT) (LOCATED BEHIND COUCH)





- JM 14 WHT
- NF 14 WHT
- NC 14 WHT
- NE 14 WHT
- ND 14 WHT
- FFE 12 WHT
- UK 16 WHT
- WE 14 WHT
- PM 14 WHT
- HT-1 16 WHT
- JP 14 WHT
- JX 14 WHT
- JY 12 WHT
- GL 16 WHT
- KF 16 WHT

- BATTERY DISCONNECT SWITCH
- 1-KF 16 WHT
 - 2-LH 16 YEL
 - 3-LJ 16 YEL
 - 4-LJ 16 YEL
 - 5-LG 16 YEL
 - 6-KF 16 WHT
 - 7-
 - 8-

- SOLAR MONITOR PANEL
- 1-HS 16 YEL
 - 2-HT 16 WHT

- CONNECTS TO WIRE ASM-ROOF (SHT 4, C-8) (LOCATED BEHIND MONITOR PANEL)
- 1-A 14 YEL
 - 2-DJ 16 YEL
 - 3-DK 16 WHT
 - 4-DL 16 YEL
 - 5-DM 16 WHT
 - 6-HS 16 YEL
 - 7-HT 16 WHT
 - 8-JA 12 YEL

- 9-JB 14 YEL
- 10-JD 14 YEL
- 11-JM 14 WHT
- 12-JP 14 WHT
- 13-KG 14 YEL
- 14-KH 14 YEL
- 15-KJ 14 YEL

- CONNECTS TO WIRE ASM-ROOF (SHT 4, A-7) (LOCATED BEHIND MONITOR PANEL)
- 1-HHY 16 WHT
 - 2-HHZ 16 YEL
 - 3-JJA 16 YEL
 - 4-JJB 16 YEL

- AWNING CONTROL BOX
- 1-HHY 16 WHT
 - 2-HHZ 16 YEL
 - 3-JJA 16 YEL
 - 4-JJB 16 YEL

- WATER PUMP
- JS 12 YEL
 - JY 12 WHT

- WIRE ASM-HOLDING TANK
- 1-XJ 16 YEL
 - 2-GL 16 WHT

- WIRE ASM-WATER TANK
- 1-XH 16 YEL
 - 2-GL 16 WHT

- THERMOSTAT
- 1-JB 14 YEL
 - 2-JM 14 WHT
 - 3-JJ 14 YEL
- FURNACE
- 1-JM 14 WHT
 - 2-JJ 14 YEL
 - 3-JB 14 YEL
 - 4-



- KF
- LJ
- LG
- LH

- HT
- HS
- JB
- A
- KJ
- KH
- KG
- DM
- DL
- DJ
- DK
- JA
- JD
- JM
- JP

WIRING DIAGRAM-COACH
(WIRE ASM 142916-01-000 REV.6)


FIRST USED: 03 G33V

TITLE: DO NOT SCALE DRAWING

WIRING DIAGRAM-BODY, 12V

SHEET 2 PART NO 141037

02/28/03



CONNECTS TO WIRE ASM-RIGHT (SHT 3, D-10) (LOCATED BELOW GALLEY CABINETS)

- 1-JG 14 YEL
- 2-LP 16 YEL
- 3-MM 14 YEL
- 4-NM 14 YEL
- 5-NW 14 YEL
- 6-PL 14 YEL

CONNECTS TO WIRE ASM-ROOF (SHT 4, B-8) (LOCATED BEHIND MONITOR PANEL)

- 1-ND 14 WHT
- 2-NE 14 WHT
- 3-NF 14 WHT
- 4-PC 14 YEL
- 5-PE 14 YEL
- 6-PF 14 YEL
- 7-PL 14 YEL
- 8-WX 14 YEL
- 9-

CONNECTS TO WIRE ASM-SIDEWALL (SHT 5, C-3) (LOCATED BELOW HEAD OF BED)

- 1-JC 14 YEL
- 2-NC 14 WHT

GALLEY SWITCH
JE 14 YEL
A 14 YEL

AISLE LAMP SWITCH
JF 14 YEL
PH 14 YEL

AISLE LAMP
PH 14 YEL
NF 14 WHT

MAKEUP LAMP SWITCH
JF 14 YEL
PD 14 YEL

MAKEUP LAMP
PD 14 YEL
NF 14 WHT










MAKEUP LAMP
PD 14 YEL
NF 14 WHT


SHOWER LAMP SWITCH
JF 14 YEL
PF 14 YEL

TOILET LAMP SWITCH
JF 14 YEL
PE 14 YEL

VENT FAN UP/DOWN SWITCH
KG 14 YEL
JM 14 WHT
KH 14 YEL
JB 14 YEL

VENT FAN ON/OFF SWITCH
JB 14 YEL
KJ 14 YEL






4 SEE MANUFACTURER'S DIAGRAM FOR ADDITIONAL INFORMATION.

3 GROUNDS ARE SHOWN AS A SINGLE LINE FOR EASE IN TRACING. EACH GROUND CIRCUIT IS SEPERATE IN THE HARNESS.

2 NOT A SPLICE POINT. INDICATES ENTRY INTO WIRING HARNESS.

1. SPLICES ARE THEORETICAL AND MAY DIFFER IN THE HARNESS.

NOTES:




WIRING DIAGRAM-RIGHT (WIRE ASM 141494-01-000 REV.E)

FIRST USED	03 G33V
TITLE	DO NOT SCALE DRAWING
TITLE	WIRING DIAGRAM-BODY, 12V
SHEET 3	PART NO 141037


- U 8 GRN
- L 6 GRN
- JP 14 WHT
- EU 16 WHT
- UK 16 WHT
- WE 14 WHT
- MS 14 WHT
- PM 14 WHT
- NE 14 WHT

- U 8 GRN
- L 6 GRN
- K 6 BLK









- 4 SEE MANUFACTURER'S DIAGRAM FOR ADDITIONAL INFORMATION.
 - 3 GROUNDS ARE SHOWN AS A SINGLE LINE FOR EASE IN TRACING. EACH GROUND CIRCUIT IS SEPERATE IN THE HARNESS.
 - 2 NOT A SPLICE POINT. INDICATES ENTRY INTO WIRING HARNESS.
1. SPLICES ARE THEORETICAL AND MAY DIFFER IN THE HARNESS.

NOTES:




WIRING DIAGRAM-ROOF (WIRE ASM 142914-01-000 REV.F)


FIRST USED	03 G33V
DO NOT SCALE DRAWING	
TITLE:	WIRING DIAGRAM
SHEET 4	PART NO 141037




FIRST USED	03 G33V
TITLE	DO NOT SCALE DRAWING
TITLE	WIRING DIAGRAM-BODY, 12V
SHEET 5	PART NO 141037




WIRING DIAGRAM-EXTENSION, 2 PIN
(WIRE ASM 133572-01-010 REV.E)



WIRING DIAGRAM-EXTENSION, 2 PIN
(WIRE ASM 133572-01-018 REV.E)



WIRING DIAGRAM-EXTENSION, 2 PIN
(WIRE ASM 133572-01-006 REV.E)



WIRING DIAGRAM-SOFA,SGL REST EASY
(WIRE ASM 136028-01-000 REV.A)

FIRST USED	03 G33V
TITLE	DO NOT SCALE DRAWING
SHEET 6	WIRING DIAGRAM-BODY, 12V
PART NO	141037