




DANGER

Danger of electrical shock, burns or death. Always remove all power sources before attempting any repair, service or diagnostic work. Power can be present from shore power, generator, inverter or battery. All power sources must be disabled and secured before performing any service.




CAUTION

If you lack the skills, tools or equipment to perform diagnostic or repair work leave such work to an authorized Winnebago Industries dealer or other qualified shop.



WIRING DIAGRAM-CHASSIS (WIRE ASM 148703 REV-D)



WIRING DIAGRAM-ELECTRICAL BOX (WIRE ASM 124125-05 REV L)

		COPYRIGHT 2004 WINNEBAGO INDUSTRIES, INC.
DFTR	ORIG. DATE	
CHR	ALL DIMENSIONS ARE IN MILLIMETERS	
P.E.		
M.E.	FIRST USED	05 D27C
DSNR		
UNSPECIFIED TOLERANCES ARE:		MATERIAL:
WHOLE DIM (XX)	:	
ONE-PLACE (X,XX)	:	
TWO-PLACE (X,XX)	:	
ANGLE	:	
THIRD ANGLE PROJECTION		
DO NOT SCALE DRAWING		
TITLE: WIRING DIAGRAM-BODY, 12V		
SHEET 1 of 4	PART NO	148420

F1

D


C

B


A

- 1-LB 16 WHT
- 2-KX 16 YEL
- 3-LA 16 YEL
- 4-LC 16 WHT
- 5-ER 16 YEL
- 6-ES 16 YEL
- 7-JT 16 YEL
- 8-LN 16 WHT
- 9-LM 16 WHT
- 10-LL 16 WHT
- 11-LP 16 YEL
- 12-DY 16 WHT
- 13-MM 14 YEL
- 14-KS 14 YEL
- 15-KU 14 YEL


CONNECTS TO WIRE ASM-COACH (SHT 2, D-4) (LOCATED BELOW GALLEY)




5 CONNECTS TO WIRE ASM-ELECTRICAL BOX (SHT 1, D-4) (LOCATED IN FRONT RIGHT COMPT.)



2 CONNECTS TO ELECTRIC STEP




- A-KA 12 YEL
- B-WH 14 YEL
- C-KD 18 WHT
- D-ES 16 YEL




- 16 YEL
- 16 WHT

CONNECTS TO BATTERY DISCONNECT (LOCATED IN BASE OF REFRIG. CABT.)



- 1-KF 16 WHT
- 2-LH 16 YEL
- 3-LJ 16 YEL
- 4-LJ 16 YEL
- 5-LG 16 YEL
- 6-KF 16 WHT
- 7-
- 8-

5 CONNECTS TO WIRE ASM-ELECTRICAL BOX (SHT 1, C-5) (LOCATED IN FRONT RIGHT COMPT.)




- 1-
- 2-
- 3-ER 16 YEL
- 4-
- 5-LG 16 YEL
- 6-FM 14 WHT
- 7-LR 14 YEL
- 8-
- 9-WH 14 YEL
- 10-KE 14 YEL
- 11-LH 16 YEL
- 12-
- 13-LJ 16 YEL
- 14-
- 15-KA 12 YEL

CONNECTS TO WIRE ASM-COACH (SHT 2, D-23) (LOCATED BELOW GALLEY)




- 1-JD 14 YEL
- 2-ND 14 WHT

- ND
- JD
- LR
- LB
- KX
- LA
- LC
- MM
- DY
- KS
- KU
- WP




- 1-KE 14 YEL
- 2-LR 14 YEL
- 3-WP 10 YEL
- 4-LB 16 WHT
- 5-KX 16 YEL
- 6-LA 16 YEL
- 7-LC 16 WHT
- 8-MM 14 YEL
- 9-DY 16 WHT
- 10-KS 14 YEL
- 11-KU 14 YEL
- 12-JD 14 YEL
- 13-ND 14 WHT
- 14-
- 15-




CONNECTS TO GENERATOR


- A-LN 16 WHT
- B-LM 16 WHT
- C-LL 16 WHT
- D-
- E-
- F-LP 16 YEL
- G-
- H-




ELECTRIC STEP DOOR JAMB SWITCH




GROUND STUD (UNDER GALLEY CABINET)




ON CHASSIS RAIL BEHIND BATTERY COMPARTMENT



IN COMPT BEHIND STEP





ELECTRICAL BOX (LOCATED IN FRONT RIGHT COMPT.)



CCY

- NOTES:
- 5 SEE WIRING DIAGRAM-ELECTRICAL BOX FOR ADDITIONAL INFORMATION.
 - 4 CCY IS PART OF WIRE ASM-CHASSIS. SEE WIRING DIAGRAM-CHASSIS FOR ADDITIONAL INFORMATION.
 - 3 TIE BACK IN LOOM. WIRE IS PART OF WIRE ASM-ELECTRICAL BOX BUT NOT USED.
 - 2 SEE MANUFACTURER'S DIAGRAM FOR ADDITIONAL INFORMATION.
 - 1 SEE WIRING DIAGRAM-AUTO FOR ADDITIONAL INFORMATION.



WIRING DIAGRAM-COACH
(WIRE ASM 148702 REV-C)


FIRST USED: 05 D27C



DO NOT SCALE DRAWING

TITLE: WIRING DIAGRAM-BODY, 12V

SHEET 2 PART NO 148420

D
C
B
A






3 GROUND ARE SHOWN AS A SINGLE LINE FOR EASE IN TRACING. EACH GROUND CIRCUIT IS SEPERATE IN THE HARNESS.


2 NOT A SPLICE POINT. INDICATES ENTRY INTO WIRING HARNESS.

1. SPLICES ARE THEORETICAL AND MAY DIFFER IN THE HARNESS.


CONNECTS TO
WIRE ASM-COACH
(SHT 2, A-17)
(IN REAR SHOWER WALL)



- 1-JB 14 YEL
- 2-
- 3-PL 14 YEL
- 4-NF 14 WHT
- 5-PF 14 YEL
- 6-NC 14 WHT
- 7-WX 14 YEL
- 8-PC 14 YEL
- 9-JM 14 WHT
- 10-PE 14 YEL
- 11-XS 16 YEL
- 12-XP 16 YEL
- 13-XR 16 YEL
- 14-CS 16 WHT
- 15-GGR 16 YEL




CONNECTS TO
WIRE ASM-COACH
(SHT 2, A-11)
(IN REAR SHOWER WALL)




WX NF PC PE PF GGR CS XR XS XP NC PL JM JB


HALL
CEILING
LAMP




GALLEY
CEILING
LAMP




BEDROOM
CEILING
LAMP




BATH
CEILING
LAMP




SHOWER
LAMP




BATH
VENT




GALLEY
VENT
FAN



FRONT
LOUNGE
CEILING
LAMP



REAR
LOUNGE
CEILING
LAMP



GGR CS XR XS XP

GGR 16 YEL

CS 16 WHT

XR 16 YEL






XS 16 YEL

XP 16 YEL



WIRING DIAGRAM-ROOF
(WIRE ASM 148618 REV-C)

FIRST USED	05 D27C
DO NOT SCALE DRAWING	
TITLE	WIRING DIAGRAM-BODY, 12V
SHEET 3	PART NO 148420



FIRST USED	05 D27C
DO NOT SCALE DRAWING	
TITLE	WIRING DIAGRAM-BODY, 12V
SHEET 4	PART NO 148420