




DANGER

Danger of electrical shock, burns or death. Always remove all power sources before attempting any repair, service or diagnostic work. Power can be present from shore power, generator, inverter or battery. All power sources must be disabled and secured before performing any service.



CAUTION

If you lack the skills, tools or equipment to perform diagnostic or repair work leave such work to an authorized Winnebago Industries dealer or other qualified shop.



FOR PRODUCTION PURPOSES ONLY.
 SEE WIRING DIAGRAM-AUTO FOR ADDITIONAL INFORMATION.
 SEE MANUFACTURERS DIAGRAM FOR ADDITIONAL INFORMATION.
 GROUNDS ARE SHOWN AS A SINGLE LINE FOR EASE IN TRACING. EACH GROUND CIRCUIT IS SEPERATE IN THE HARNESS.
 NOT A SPLICE POINT. INDICATES ENTRY INTO WIRING HARNESS.
 SPLICES ARE THEORETICAL AND MAY DIFFER IN THE HARNESS.

WIRING DIAGRAM-CHASSIS
 (WIRE ASM-149010 REV H)

WINNEBAGO COPYRIGHT 2004 WINNEBAGO INDUSTRIES, INC.


| | |
|------|-----------------------------------|
| DFTR | ORIG. DATE |
| CHKR | ALL DIMENSIONS ARE IN MILLIMETERS |
| P.E. | FIRST USED |
| M.E. | 05 G38J |
| DSNR | |


UNSPECIFIED TOLERANCES ARE:
 WHOLE DIM (X) :
 ONE-PLACE (X.X) :
 TWO-PLACE (X.XX) :
 ANGLE :

MATERIAL:
 THIRD ANGLE PROJECTION

DO NOT SCALE DRAWING

TITLE: WIRING DIAGRAM-BODY, 12V
 SHEET 1 OF 6 PART NO 148936
 REF: NONE 1 7/19/2004







WIRING DIAGRAM-ROOF
(WIRE ASM-149134 REV G)



| | | |
|------------|-------------------------|--------|
| FIRST USED | 05 G38J | |
| TITLE | DO NOT SCALE DRAWING | |
| | WIRING DIAGRAM-BODY,12V | |
| SHEET 3 | PART NO | 148936 |

D
C
B
A







- 5 SEE WIRING DIAGRAM-AUTO FOR ADDITIONAL INFORMATION.
- 4 SEE MANUFACTURERS DIAGRAM FOR ADDITIONAL INFORMATION.
- 3 GROUNDS ARE SHOWN AS A SINGLE LINE FOR EASE IN TRACING. EACH GROUND CIRCUIT IS SEPERATE IN THE HARNESS.
- 2 NOT A SPLICE POINT. INDICATES ENTRY INTO WIRING HARNESS.
1. SPLICES ARE THEORETICAL AND MAY DIFFER IN THE HARNESS.

NOTES:



- 1-JC 14 YEL
- 2-NC 14 WHT
- 3-KK 16 YEL
- 4-KL 16 WHT
- 5-KN 16 YEL
- 6-KP 16 WHT


CONNECTS TO WIRE ASM-SIDEWALL (SHT 4, B-5) (LOCATED IN BD RM OVHD)




WIRING DIAGRAM-OVHD
(WIRE ASM 149135 REV C)

| | |
|------------|--------------------------|
| FIRST USED | 05 G38J |
| TITLE | DO NOT SCALE DRAWING |
| TITLE | WIRING DIAGRAM-BODY, 12V |
| SHEET 4 | PART NO 148936 |


1 7/19/2004



WIRING DIAGRAM-EXTENSION, 2 PIN
(WIRE ASM 149130 REV B)



WIRING DIAGRAM-SIDEWALL
(WIRE ASM 149131 REV E)



WIRING DIAGRAM-TV CABT, SIDE
(WIRE ASM 149137 REV E)

| | |
|------------|--------------------------|
| FIRST USED | 05 G38J |
| TITLE | DO NOT SCALE DRAWING |
| | WIRING DIAGRAM-BODY, 12V |
| SHEET 5 | PART NO 148936 |

