



DANGER

Danger of electrical shock, burns or death. Always remove all power sources before attempting any repair, service or diagnostic work. Power can be present from shore power, generator, inverter or battery. All power sources must be disabled and secured before performing any service.




CAUTION

If you lack the skills, tools or equipment to perform diagnostic or repair work leave such work to an authorized Winnebago Industries dealer or other qualified shop.

| | |
|-------------|---------|
| DRAWING NO. | FEATURE |
| 152463-01 | (WIN) |
| 152463-02 | (ITA) |

| | | |
|----------|-----------------|----------|
| RELEASE | REV/DATE | DWG NO |
| | A | 152463 |
| REV ZONE | REVISION RECORD | DATE |
| | | DFT-0816 |




- 3 CONNECT TELEPHONE WIRE TO MATCHING COLORS ON PLATE-WALL,PHONE/DUAL COAX.
- 2 PLACE CROSS LOCATOR ON SENSORS OVER DIMPLES ON TANK.

1. ALL WIRES TO BE SECURED WITH CLAMP 10495 OR 10497 OR WIRE TIE 8343 OR 108046 EVERY 600MM, USE SCREW G67-XX-XXX OR G56-XX-XXX AS APPROPRIATE FOR INSTALLATION.

NOTES:

SWITCH - WATER PUMP
108357-15-000
ACTUATOR
108356-04-CHT

PLATE-WALL,PHONE/DUAL COAX
149557-02-CHT
SCREW
G39-08-08U (2)



VIEW AA

FOR ELECTRICAL TORQUE SPECIFICATIONS SEE DWG NO. 128783-01-000

FOR ELECTRICAL CALLOUTS SEE DWG NO. 121339-01-000


- (ITA) ITASCA ONLY
- (WIN) WINNEBAGO ONLY
- (265) CODES/STANDARDS-CSA/CMVSS
- (1B1) CODES/STANDARDS USA

| | | | |
|------------------|------------|---|---|
| WINNEBAGO | | COPYRIGHT 2004 WINNEBAGO INDUSTRIES, INC. | |
| DFT# | ORIG. DATE | ALL DIMENSIONS ARE IN MILLIMETERS | |
| CHK# | | FIRST USED | |
| P.E. | | 06 D30B | |
| M.E. | | UNSPECIFIED TOLERANCES ARE: | |
| DSNR | | MATERIAL: | |
| | | WHOLE DIM (X) | : |
| | | ONE-PLACE (X.X) | : |
| | | TWO-PLACE (X.XX) | : |
| | | ANGLE | : |
| | | THIRD ANGLE PROJECTION | |

DO NOT SCALE DRAWING


TITLE: WIRING INSTL-BODY,12V
SHEET 1 of 4 PART NO 152463

REF: 1 10/17/2005



SWITCH-ROCKER
135740-01-CHT (2)
SWITCH-BASE
135741-01-CHT
SWITCH-BEZEL
135742-15-CHT
SCREW
G11-08-08U (4)

DETAIL BA




SWITCH-ROCKER
135740-06-CHT
SWITCH-BASE
135741-01-CHT
SWITCH-BEZEL
135742-35-CHT
SCREW
G11-08-08U (2)

DETAIL BD 53Z

TV-COLOR 13" DC
86231-10-000
CABLE ASM-COAX
87105-01-009
BRACKET-TV
144819-01-CHT
SCREW
G67-10-12B (18)
BRACKET-Z W/HOLES
146783-01-CHT

LOW

SWITCH
DETAIL BC



SWITCH-ROCKER
135740-01-CHT
SWITCH-BASE
135741-01-CHT
SWITCH-BEZEL
135742-45-CHT
SCREW
G11-08-08U (2)

DETAIL BC

LIGHT-READING
132427-01-CHT (2)
SCREW
G13-06-16U (6)

WIRE ASM-OVHD
148704-01-000

SWITCH
DETAIL BB

SWITCH ASM-SLIDEOUT
138173-04-000
LABEL
116549-01-000

WALLPLATE-TV
76319-27-000

LAMP
93575-37-CHT
93575-38-CHT
BULB
117805-01-000 (2)
CONNECTOR
58028-01-000 (2)
SCREW
G11-06-10J (2)

WIN
ITA

SWITCH-WATER HEATER
DETAIL BD

PANEL-MONITOR
134940-06-CHT
SCREW
G11-08-08U (4)

THERMOSTAT
135618-03-CHT 250
135618-01-CHT 29J
GASKET-THERMOSTAT
134588-09-000 4


PLATE-WALL, TELEPHONE 2
93253-01-CHT
RECEPTACLE-12V
132958-01-000
DETAIL BC

SWITCHES
DETAIL BA

SWITCH
135740-01-CHT
BASE
135741-01-CHT
BEZEL
135742-07-CHT
SCREW
G11-08-08U (2)

SWITCH
135740-01-CHT
BASE
135741-01-CHT
BEZEL
135742-07-CHT
SCREW
G11-08-08U (2)


WIRE ASM-COACH
PASSES THRU FLOOR
IN THIS AREA



SWITCH-ROCKER
135740-01-CHT
SWITCH-BASE
135741-01-CHT
SWITCH-BEZEL
135742-01-CHT
SCREW
G11-08-08U (2)

DETAIL BB

- 53Z WTR HTR-6GAL/110/LP/MTR/AUTO
- LOW TV-REAR
- 29J AC HEAT PUMP-1
- 250 A/C ROOF AIR (1) 14,800 BTU
- ITA ITASCA ONLY
- WIN WINNEBAGO ONLY
- 265 CODES/STANDARDS-CSA/CMVSS
- 1B1 CODES/STANDARDS USA



DETAIL BC

3. ALL WIRES TO BE SECURED WITH CLAMP 10495 OR 10497 OR WIRE TIE 8343 OR 108046 EVERY 600MM, USE SCREW G67-XX-XXX OR G56-XX-XXX AS APPROPRIATE FOR INSTALLATION.








- 2 CONNECT TELEPHONE WIRE TO MATCHING COLORS ON PLATE-WALL, TELEPHONE.
- 1 SEE WIRING INSTL-FRONT END FOR WIRING INFORMATION.

4 INSTALL GASKET ON BACK SIDE OF ONE PLACE AFTER INSTALLATION OF THERMOSTAT, MAKING SURE THAT THE GASKET COVERS AND SEALS THE HOLE THAT THE WIRES PASS THROUGH.

FOR ELECTRICAL TORQUE SPECIFICATIONS SEE DWG NO. 128783-01-000

FOR ELECTRICAL CALLOUTS SEE DWG NO. 121339-01-000

| | |
|----------------------------------|-------------------|
| FIRST USED | |
| 06 D30B | |
| DO NOT SCALE DRAWING | |
| TITLE: WIRING INSTL-BODY, 12V | |
| SHEET 2 | PART NO 152463 |



- NOTES:
- 5 REFERENCE ONLY. SEE LOAD CENTER/ATS ASM FOR ADDITIONAL INFORMATION.
 - 4 WRAP BRACKET LEGS AROUND ANTENNA BASE.
 - 3 WITHOUT (ID5) USE ADAPTER AND CONNECT GRN COAX TO GRN/GRN COAX.
 - 2 SENSOR SUPPLIED WITH SATELLITE ASSEMBLY
 - 1 SEE DWG 76319-01-000 FOR INSTALLATION INSTRUCTIONS.

FOR ELECTRICAL TORQUE SPECIFICATIONS SEE DWG NO. 128783-01-000

FOR ELECTRICAL CALLOUTS SEE DWG NO. 121339-01-000

- (1JM) HOME THEATER SOUND SYSTEM
- (ID5) ENTERTAINMENT CENTR/EXT W/CD
- (480) SATELLITE DISH & ELEV.SENSOR
- (265) CODES/STANDARDS-CSA/CMVSS
- (1B1) CODES/STANDARDS USA

| | |
|------------|------------------------|
| FIRST USED | 06 D30B |
| TITLE | DO NOT SCALE DRAWING |
| | WIRING INSTL-BODY, 12V |
| SHEET 4 | PART NO 152463 |