




DANGER

Danger of electrical shock, burns or death. Always remove all power sources before attempting any repair, service or diagnostic work. Power can be present from shore power, generator, inverter or battery. All power sources must be disabled and secured before performing any service.



CAUTION

If you lack the skills, tools or equipment to perform diagnostic or repair work leave such work to an authorized Winnebago Industries dealer or other qualified shop.



- 6 SEE MANUFACTURERS DIAGRAM.
- 5 POWER CORD SUPPLIED WITH INVERTER.
- 4 WIRE ROUTED IN ROOF.
- 3 WIRE ROUTED IN SIDEWALL.
- 2 WIRE ROUTED THRU FLOOR.
- 1 ALL WIRES DOWN STREAM AND INCLUDING THIS OUTLET ARE GROUND FAULT CIRCUIT INTERRUPT PROTECTED.

NOTES:

265 CODES/STANDARDS-CSA/CMVSS


12D ELECTRICAL SYSTEM 30 AMP

1B1 CODES/STANDARDS USA

1B1 265 12D



COPYRIGHT 2010
WINNEBAGO
INDUSTRIES, INC.

| | | | |
|----------------------------------|--|---|-----|
| DFT# | | ORIG. DATE | |
| CHK# | | ALL DIMENSIONS ARE IN MILLIMETERS | |
| P.E. | | FIRST USED | |
| M.E. | | 11 H25R | |
| DSNR | | | |
| UNSPECIFIED TOLERANCES ARE: | | MATERIAL: | |
| WHOLE DIM (X) ± | | | |
| ONE-PLACE (X,.X) ± | | | |
| TWO-PLACE (X,.XX) ± | | | |
| ANGLE ± | | | |
| THIRD ANGLE PROJECTION | |  | |
| DO NOT SCALE DRAWING | | | |
| TITLE: WIRING DIAGRAM-BODY, 110V | | | |
| SHEET 1 OF 1 | | PART NO | REV |
| | | 175516 | |

FOR ELECTRICAL
TORQUE
SPECIFICATIONS
SEE DWG NO.
128783-01-000



FOR
ELECTRICAL
CALLOUTS
SEE DWG NO.
121339-01-000