



DANGER

Danger of electrical shock, burns or death. Always remove all power sources before attempting any repair, service or diagnostic work. Power can be present from shore power, generator, inverter or battery. All power sources must be disabled and secured before performing any service.




CAUTION

If you lack the skills, tools or equipment to perform diagnostic or repair work leave such work to an authorized Winnebago Industries dealer or other qualified shop.

DRAWING NO.	SHEET	SERIES
174637-01	1	E-SERIES (19V)
174637-02	2	700-SERIES
174637-03	3	500,H-SERIES
174637-04	4	J,P,R-SERIES
174637-05	5	D,E-SERIES (255)
174637-06	6	200-SERIES

RELEASE	REV DATE	DWG NO	174637
REV ZONE	REVISION RECORD	DATE	DTR-ORIG



WIRE ASM-RADIO ADAPTOR
(SEE WIRING INSTL-FRONT END)

ANTENNA LEAD

RADIO-AM/FM STEREO,CD PLAYER 1
172120-09-000
BRACE-RADIO 2
173120-01-CHT
SCREW
G39-10-12U

HARNESS-RADIO
172120-03-000

- (255) RADIO-AM/FM/CD/DVD PLAYER
- (19V) RADIO-AM/FM STEREO CD PLAYER
- (265) CODES/STANDARDS-CSA/CMVSS
- (1B1) CODES/STANDARDS USA

(1B1) (265) (19V)




DTR	ORIG. DATE
CHKR	ALL DIMENSIONS ARE IN MILLIMETERS
P.E.	
M.E.	FIRST USED
DSNR	11 E-SERIES
UNSPECIFIED TOLERANCES ARE:	
WHOLE DIM (X)	:
ONE-PLACE (X.X)	:
TWO-PLACE (X.XX)	:
ANGLE	:
THIRD ANGLE PROJECTION	
DO NOT SCALE DRAWING	REFER TO ES0018 FOR FASTENER TIGHTENING GUIDELINES
TITLE: RADIO INSTL	
SHEET 1 OF 6	PART NO 174637 REV

- NOTES:
- 2 ATTACH TO BOLT ON BACK OF RADIO & SCREW TO TUBE UNDER DASH.
 - 1 BEND TABS ON ALL 4 SIDES TO SECURE RADIO MOUNTING BRACKET TO DASH MOUNTING BRACKET.

FOR ELECTRICAL TORQUE SPECIFICATIONS SEE DWG NO. 128783-01-000

FOR ELECTRICAL CALLOUTS SEE DWG NO. 121339-01-000



5. APPLY TAPE 8363-01-000 AS NECESSARY TO SECURE NON-LOCKING CONNECTIONS.
- 4 PLUG I-POD CABLE INTO LEAD ON BACK OF RADIO MARKED 'I-POD'. ROUTE CABLE TO THE LEFT OF RADIO. WIRE TIE EXCESS CABLE UNDER DASH IN THE AREA LEFT OF THE RADIO. LEAVE 200 MM OF CABLE IN THE MOTOR COVER BEVERAGE TRAY. MAKE SURE CABLE DOES NOT GET PINCHED BY MOTOR COVER.
- 3 CONNECT TO "CAMERA 1" CABLE ON RADIO FOR REAR CAMERA.
- 2 TO BE SUPPLIED LOOSE IN WINNEBAGO OWNERS CASE.
- 1 ENGAGE T-RAIL ON BOTTOM OF RADIO UNTIL LOCKED IN PLACE.

- 19R RADIO/REARVIEW MONITOR SYS
- 70C RADIO - SATELLITE
- 19V RADIO-AM/FM STEREO CD PLAYER
- 265 CODES/STANDARDS-CSA/CMVSS
- 1B1 CODES/STANDARDS USA



FIRST USED	
11 700-SERIES	
DO NOT SCALE DRAWING	
TITLE: RADIO INSTL	
SHEET 2	PART NO 174637 REV

FOR ELECTRICAL TORQUE SPECIFICATIONS SEE DWG NO. 128783-01-000

FOR ELECTRICAL CALLOUTS SEE DWG NO. 121339-01-000

500-SERIES 19V

H-SERIES 500-SERIES 19R




- 8.** APPLY TAPE 8363-01-000 AS NECESSARY TO SECURE NON-LOCKING CONNECTIONS.
- 7** CONNECT TO "CAMERA 1" CABLE ON RADIO FOR REAR CAMERA.
- 6** SUPPLIED WITH RADIO MOUNT BRACKET.
- 5** PLUG I-POD CABLE INTO LEAD ON BACK OF RADIO MARKED I-POD. DRILL 16 MM DIAMETER HOLE IN THE TRAY ABOVE THE RADIO. THE HOLE IS TO BE LOCATED ON THE PASSENGER SIDE OF THE TRAY 50 MM FROM THE END NEAREST THE WINDSHIELD. ROUTE I-POD CABLE INTO THE TRAY AND LEAVE 200 MM OF WIRE IN THE TRAY.
- 4** INSTALL REAR SUPPORT TO TOP EDGE OF RADIO.
- 3** TO BE SUPPLIED LOOSE IN WINNEBAGO OWNERS CASE.
- 2** BEND TABS ON ALL 4 SIDES TO SECURE MOUNTING BRACKET TO DASH OPENING.
- 1** SUPPLIED WITH RADIO.

- 19R RADIO/REARVIEW MONITOR SYS
- 70C RADIO - SATELLITE
- 19V RADIO-AM/FM STEREO CD PLAYER
- 265 CODES/STANDARDS-CSA/CMVSS
- 1B1 CODES/STANDARDS USA


11 500,H-SERIES	
DO NOT SCALE DRAWING	
TITLE: RADIO INSTL	
SHEET 3	PART NO. 174637 REV

FOR ELECTRICAL TORQUE SPECIFICATIONS SEE DWG NO. 128783-01-000

FOR ELECTRICAL CALLOUTS SEE DWG NO. 121339-01-000



DETAIL DA
APPLY LABEL OVER THIS BUTTON



- RADIO-AM/FM/CD
172120-06-000
HARNESS
172120-03-000
REMOTE CONTROL
172120-07-000
CABLE-ADAPTER
172120-08-000
- RADIO-INFOTAINMENT
176654-07-000
KIT-RADIO MOUNTING
176654-02-000
TRIM-RADIO MOUNTING
177501-01-CHT
REMOTE-NAVIGATION/RADIO
176654-04-000
LABEL
176654-06-CHT
- REMOTE CONTROL
163142-13-000
- SUPPORT-RADIO
169973-01-CHT
SCREW
G11-10-08U
NUT-SPEED
40921-12-000
- SUPPORT-RADIO
174273-01-CHT
SCREW
G11-10-08U
NUT-SPEED
40921-12-000
- SUPPORT-RADIO
174061-01-CHT
BOLT
G42-04-12U
SCREW
G18-10-08U (2)

CABLE ASM-I-POD INTERFACE 163142-12-000 70C 15C OR 19R

ANTENNA LEAD FROM BEHIND DASH

WIRE ASM-IP, MAIN

RECEIVER-INFRARED 163142-11-000

14. APPLY TAPE 8363-01-000 AS NECESSARY TO SECURE NON-LOCKING CONNECTIONS.

- 13 P-SERIES
- 12 R-SERIES
- 11 ATTACH TO RADIO WITH SCREW SUPPLIED WITH RADIO.
- 10 MOUNT GPS ANTENNA ON TOP OF DEFROST PLENUM.
- 9 APPLY LABEL OVER "WB" BUTTON. SEE DETAIL DA.
- 8 CONNECT TO "CAMERA 1" CABLE ON RADIO FOR REAR CAMERA.
- 7 J-SERIES
- 6 WORKHORSE AND FREIGHTLINER CHASSIS.
- 5 PLUG I-POD CABLE INTO LEAD ON BACK OF RADIO MARKED 'I-POD' FOR UNITS WITHOUT GPS. ROUTE CABLE UP LEFT A-PILLAR AND INTO OVERHEAD CABINET ABOVE DRIVER. LEAVE 600 MM OF CABLE IN OVERHEAD TIED UP WITH WIRE TIE 8343-01-000. FOR UNITS WITH GPS. CONNECT TO IPOD DOCK.


- 4 INSTALL PER DRAWING 170205.
- 3 TO BE SUPPLIED LOOSE IN WINNEBAGO OWNERS CASE.
- 2 BEND TABS ON ALL 4 SIDES TO SECURE MOUNTING BRACKET TO DASH OPENING.
- 1 SUPPLIED WITH RADIO.





- 19R RADIO/REARVIEW MONITOR SYS
- 15D GPS-NAVIGATION SYSTEM
- 15C GPS-NAVIGATION SYSTEM W/O
- 70C RADIO - SATELLITE
- 19V RADIO-AM/FM STEREO CD PLAYER
- 265 CODES/STANDARDS-CSA/CMVSS
- 1B1 CODES/STANDARDS USA

1B1	265	19V
FIRST USED		
11 J,P,R-SERIES		
DO NOT SCALE DRAWING		
TITLE: RADIO INSTL		
SHEET 4	PART NO. 174637	REV

FOR ELECTRICAL TORQUE SPECIFICATIONS SEE DWG NO. 128783-01-000

FOR ELECTRICAL CALLOUTS SEE DWG NO. 121339-01-000






NOTES:

2 E-SERIES ONLY. NOT USED ON D-SERIES.

1 CONNECTS IN-LINE OF YELLOW VIDEO CABLE. WRAP BOTH ENDS OF FILTER CONNECTIONS WITH TAPE 8363-01-000 TO SECURE FILTER TO WIRE ASM.

- 401 INVERTER-DC/AC, 1000 WATT
- 40A INVERTER-DC/AC WITHOUT
- 255 RADIO/AM/FM/CD/DVD PLAYER
- 255

FIRST USED	
11 D,E-SERIES	
DO NOT SCALE DRAWING	
TITLE: RADIO INSTL	
SHEET 5	PART NO 174637 REV




- 19V RADIO 172120-14-000 KIT 172120-02-000
- 19R RADIO 172120-06-000 BRACKET 168430-04-000 REMOTE CONTROL 172120-07-000 CABLE-ADAPTER 172120-08-000
- 19N RADIO 172120-10-000 BRACKET 168430-04-000 CABLE-ADAPTOR 172120-07-000 WIRE ASM-JUMPER 170220-01-000
- 19F RADIO 182408-01-000 KIT 182408-03-000 ADAPTOR 182408-06-000 RCA-CABLE 117420-02-000

- 644 19N WIRE ASM-JUMPER, RADIO 170220-01-000 182948-01-000
- 19R 19V
- 649 DETAIL FA

- 19R HARNESS-RADIO 172120-04-000
- 644 172120-12-000
- 19V 172120-16-000
- 19F 182408-02-000

- NOTES:
- 6 PART SUPPLIED BY CANADREAM.
 - 5 NOT USED WITH 649.
 - 4 MOUNT GPS RECEIVER UNDER DASH CLOSE TO WINDSHIELD.
 - 3 TO BE SUPPLIED LOOSE IN WINNEBAGO OWNER'S CASE.
 - 2 CONNECT TO "CAMERA 1" CABLE ON RADIO FOR REAR CAMERA.
 - 1 PLUG I-POD CABLE INTO LEAD ON BACK OF RADIO MARKED "I-POD". ROUTE CABLE TO THE LEFT OF RADIO. WIRE TIE EXCESS CABLE UNDER DASH IN THE AREA LEFT OF THE RADIO. LEAVE 200 MM OF CABLE IN THE MOTOR COVER BEVERAGE TRAY. MAKE SURE CABLE DOES NOT GET PINCHED BY MOTOR COVER.



FOR ELECTRICAL TORQUE SPECIFICATIONS SEE DWG NO. 128783-01-000

FOR ELECTRICAL CALLOUTS SEE DWG NO. 121339-01-000

- 649 RENTAL - CANADREAM
- 19F RADIO/GPS/REARVIEW MONTR SYS
- 19N RADIO UPGRADE-AM/FM/CD/RMOTE
- 644 GREAT ALASKAN RENTAL PACKAGE
- 19V RADIO-AM/FM STEREO CD PLAYER
- 70C RADIO - SATELLITE
- 19R RADIO/REARVIEW MONITOR SYS
- 265 CODES/STANDARDS-CSA/CMVSS
- 1B1 CODES/STANDARDS USA

FIRST USED	
11 200-SERIES	
DO NOT SCALE DRAWING	
TITLE: RADIO INSTL	
SHEET 6	PART NO. 174637 REV