



DANGER

Danger of electrical shock, burns or death. Always remove all power sources before attempting any repair, service or diagnostic work. Power can be present from shore power, generator, inverter or battery. All power sources must be disabled and secured before performing any service.



CAUTION

If you lack the skills, tools or equipment to perform diagnostic or repair work leave such work to an authorized Winnebago Industries dealer or other qualified shop.

DRAWING NO.	MODEL
182140-01	H25R
182140-02	H25Q/H25T

RELEASE	REV/DATE A	DWG NO 182140
REV ZONE	REVISION RECORD	DATE DFR-ORIG

		H25R	H25Q/H25T	
CABLE ASM-STARTER (RED)		141415-37-063	141415-37-043	3
CABLE ASM-COACH BATTERY (YEL)		141415-52-012	141415-52-012	
CABLE ASM-COACH BATTERY GND (BLK)		133567-12-009	133567-12-009	
CABLE ASM-GENERATOR (GRN)	33F	141416-42-043	141416-42-043	3
CABLE ASM-GENERATOR GND (BLK)	33F	133567-12-006	133567-12-006	3
CABLE ASM-GENERATOR (GRN)	52G	141415-42-057	141415-42-057	3
CABLE ASM-GENERATOR GND (BLK)	52G	133566-12-017	133566-12-017	3
CABLE ASM-INVERTER FUSE (ORG)		141415-62-003	141415-62-003	
CABLE ASM-INVERTER GND (BLK)		133566-12-011	133566-12-011	
CABLE ASM-INVERTER (ORG)		141415-62-023	141415-62-023	

- 52G GEN-3.6KW ONAN LP MICROQUIET
- 33F GEN-3.2 KW ONAN DIESEL
- 265 CODES/STANDARDS-CSA/CMVSS
- 1B1 CODES/STANDARDS USA

1B1 265




DFTR	ORIG. DATE
CHKR	ALL DIMENSIONS ARE IN MILLIMETERS
P.E.	
M.E.	FIRST USED
DSNR	13 H-SERIES
UNSPECIFIED TOLERANCES ARE:	
WHOLE DIM (X)	MATERIAL:
ONE-PLACE (X.X)	
TWO-PLACE (X.XX)	
ANGLE	
THIRD ANGLE PROJECTION	
DO NOT SCALE DRAWING	REFER TO ES0018 FOR FASTENER TIGHTENING GUIDELINES
TITLE: BATTERY INSTL	
SHEET 1 OF 2	PART NO 182140 REV

- NOTES:
- SEE WIRING INSTL-CHASSIS FOR ADDITIONAL INFORMATION FOR ROUTING CABLES.
 - BATTERY CABLES ARE NOT TO BE ROUTED OVER BATTERY FILL CAPS.

FOR ELECTRICAL TORQUE SPECIFICATIONS SEE DWG NO. 128783-01-000

FOR ELECTRICAL CALLOUTS SEE DWG NO. 121339-01-000



FUSE HOLDER
115187-02-000
SCREW
G39-10-16B (2)
FUSE-150 AMP
115187-03-000

CABLE ASM-JUMPER POS
133566-01-003
(RED)

BA

CABLE ASM-INVERTER FUSE
(ORG)

CABLE ASM-COACH BATTERY GND
(BLK)

BATTERY-12V
63739-01-000 (2)

TIEDOWN ASM-BATTERY
173596-01-CHT (2)
BOLT
51387-06-000 (2)
NUT
D39-05-00B (2)
WASHER-RUBBER
184541-01-CHT (2)
BOLT
000C12-06-24B (2)

CABLE ASM-JUMPER GND
133566-11-003
(BLK)

CABLE ASM-INVERTER
(ORG)

CABLE ASM-INVERTER GND
(BLU)

TO CHASSIS
ELECTRICAL BOX

CABLE ASM-GENERATOR
(GRN) 3

CABLE ASM-COACH BATTERY
(YEL) 3

CABLE ASM-GENERATOR
(REF) 3

CABLE ASM-JUMPER GND
(REF)

CABLE ASM-JUMPER POS
(REF)

CABLE ASM-COACH BATTERY GND
(REF)

CABLE ASM-COACH BATTERY
(REF) 3

COACH BATTERIES
(REF)

VIEW BA

3 CABLES MAY BE ROUTED DIFFERENTLY DEPENDING ON FLOORPLAN.
SEE WIRING INSTL-CHASSIS FOR ADDITIONAL INFORMATION.

2. BATTERY CABLES ARE NOT TO BE ROUTED OVER BATTERY FILL CAPS.

1. CHASSIS FOR ADDITIONAL INFORMATION FOR ROUTING CABLES.

NOTES:

265 CODES/STANDARDS-CSA/CMVSS

1B1 CODES/STANDARDS USA

1B1 265

FIRST USED
13 H-SERIES

DO NOT SCALE DRAWING

TITLE:
BATTERY INSTL

SHEET 2 PART NO **182140** REV

FOR ELECTRICAL
TORQUE
SPECIFICATIONS
SEE DWG NO.
128783-01-000

X-X
FOR ELECTRICAL
CALLOUTS
SEE DWG NO.
121339-01-000