



DETAIL AA 5

CONNECT CIRCUIT TD-1  
TO BATTERY AS SHOWN  
TORQUE 19.0 NM ± 1.9 NM



DETAIL AB

TORQUE 8.0 NM ± 0.4 NM



5 MAKE SURE TO REMOVE FUSE ON WIRE ASM-CHASSIS BATTERY JUMPER BEFORE MAKING CONNECTIONS. CONNECT TD-1 TO BATTERY AS SHOWN; HAVE FUSE DROP IN THE BATTERY COMPARTMENT AND THEN RUN THE TD WIRE UNDER THE PLASTIC COVER BACK TO UNDER THE DRIVER'S SEAT WHERE YOU WILL CONNECT TO CIRCUIT TD ON THE WIRE ASM-CHASSIS. AFTER THE CONNECTIONS ARE MADE, REPLACE THE FUSE.

4 CONNECT YELLOW WIRE TO CIRCUIT LR AND CONNECT THE BLUE WIRE WITH RING TERMINAL TO THE BATTERY POST 'B+' OF THE ALTERNATOR. DISCARD RELAY AND UNUSED WIRES.

3 CUT WIRE TIE AROUND SPRINTER SEAL, ROUTE THE CHASSIS WIRING THROUGH HOLE AND WIRE TIE SEAL WITH WIRE TIE 8343-04-000.


2 SEE BATTERY INSTL. FOR ADDITIONAL INFORMATION.

1. SECURE CONDUIT 41953, TAB AS REQUIRED, OVER ALL WIRES IN CONTACT WITH SHARP EDGES.

NOTES:

7 SEE ALTERNATOR INSTL FOR CABLE ROUTING AND ADDITIONAL INFORMATION.

6 ATTACH LABEL TO SEAT PEDESTAL BASE ACCESS COVER.



265 CODES/STANDARDS-CSA/CMVSS

1B1 CODES/STANDARDS USA



1B1 265

**WINNEBAGO**  
COPYRIGHT 2024 WINNEBAGO INDUSTRIES, INC.


DSNR:		ALL DIMENSIONS ARE IN MILLIMETERS	
DFTR:			
UNSPECIFIED TOLERANCES:		MATERIAL:	
WHOLE DIM (X)	± 3		
ONE-PLACE (X.X)	± 1.5		
TWO-PLACE (X.XX)	± 0.50		
ANGLE	± 1°		
REFER TO ES0018 FOR FASTENER TIGHTENING GUIDELINES		WEIGHT: (LBS)	FIRST USED:
			24 B44E
DESCRIPTION:			
WIRING INSTL-CHASSIS			
SHEET:	ITEM/PART NO:	REV	
1 OF 2	000280088 / 35567101000		

REF: 1 08-Oct-2025






Terminal	U [V] / I [A]
1 <sup>st</sup> power with engine running	12V / 10A
2 <sup>nd</sup> battery direct power	12V / 25A
3 <sup>rd</sup> ignition power	12V / 15A



DETAIL BB  
(MERCEDES BENZ CHASSIS 2025 AND NEWER)



DETAIL BB  
(MERCEDES BENZ CHASSIS 2024 AND OLDER)

265 CODES/STANDARDS-CSA/CMVSS

1B1 CODES/STANDARDS USA

1B1 265

DESCRIPTION:

WIRING INSTL-CHASSIS

SHEET:

ITEM/PART NO:

REV

2 OF 2

000280088 / 35567101000

5

2

1285

5

4

3

2

1. SECURE CONDUIT 41953, TAB AS REQUIRED, OVER ALL WIRES IN CONTACT WITH SHARP EDGES.

NOTES:

DO NOT REUSE HARNESS FASTENERS ONCE REMOVED. ATTACH NEW FASTENER NEXT TO OEM FASTENER ON HARNESS. INSTALL NEW FASTENER INTO OEM MOUNTING LOCATION ON SEAT ASSEMBLY.

SEE COMPONENT DRAWING FOR TORQUE SPECIFICATIONS.

LOCATED UNDER DRIVER'S SEAT.

SEE BATTERY INSTL FOR ADDITIONAL INFORMATION.

1. SECURE CONDUIT 41953, TAB AS REQUIRED, OVER ALL WIRES IN CONTACT WITH SHARP EDGES.

NOTES:

TD-1  
TO CHASSIS BATTERY

FRONT  
AXLE

DATUM

TIE-WIRE 7.5IN BLACK  
008343-03-000 (2)  
MOUNT-EDGE, CABLE TIE  
000296368 / 359526-01-000 (2)  
TIE-WIRE, 8" HOLE MOUNT  
000296370 / 359527-01-000 (2)

TO WIRE ASM-RUNNING BOARD

GROMMET-RUBBER-2 OD  
023942-01-000

MM,AEX  
TO PSM  
DETAIL BB

KE,WJ  
TO SPRINTER  
WIRING  
DETAIL BA

WIRE ASM-CHASSIS POWER  
000290901 / 358321-01-000

TO WIRE ASM-COACH,PASSENGER

CABLE ASM-4 AWG RED JUMPER  
000293284 / 358689-01-000

GROMMET-RUBBER-3 OD  
023942-02-000

TO WIRE ASM-COACH,DRIVER

FUSE HOLDER-ANL/ANN WITH COVER  
000129524 / 325347-01-000  
FUSE-80 AMP, NON-DELAY  
115187-04-000  
SCREW  
G39-10-12U (4)

BRACKET-MOUNT,ASM  
000287990 / 357292-01-CHT

CLAMP  
010497-12-000 (3)  
SCREW  
G67-08-12U (3)

WIRE ASM-POWER JUMPER  
TO CHASSIS BATTERY  
(REF)

SOLENOID-SEALED,12VDC,150A  
000188488 / 335753-01-000  
SCREW  
000G50-04-08U (2)

WIRE ASM-CHASSIS POWER  
TO ECOFLOW POWER HUB  
(REF)

VIEW BC

DETAIL BA

PSM

MM (7)

CEW (2)

AEX (12)

DETAIL BB

(MERCEDES BENZ CHASSIS 2024 AND OLDER)

265 CODES/STANDARDS-CSA/CMVSS

1B1 CODES/STANDARDS USA

1B1 265

DESCRIPTION:

WIRING INSTL-CHASSIS

SHEET:

ITEM/PART NO:

REV

2 OF 2

000280088 / 35567101000